

AirLive SIP Basic Settings

SIP Basic Setting Example

SIP Basic Setting



Table of Content

Connection Diagram	3
Setting Information	4
GW A Configuration	5
GW B Configuration	7
Register Result	9
How to Dial	



Connection Diagram

GW A, GW B and IP Phone are under the IP Network. GW A and GW B register to a SIP Proxy Server





Setting Information

SIP Proxy Server

IP Address/port: Allow Reg. ID, A/C & PW: sip.airlive.com/5060 <86101, A/C: 86101, PW: 86101> <86102, A/C: 86102, PW: 86102 > <86201, A/C: 86201, PW: 86201 > <86202, A/C: 86202, PW: 86202 > <86203, A/C: 86203, PW: 86203 >

GW-A (2 port FXS)

IP Address:	211.20.96.2
Caller ID, A/C & PW :	86101, A/C: 86101, PW: 86101
	86102, A/C: 86102, PW: 86102

GW-B (2 port FXS, 2 port FXO)

IP Address:	211.20.96.3
Caller ID, A/C & PW :	86201, A/C: 86201, PW: 86201
86202, A/C:	86202, PW: 86202
86203, A/C:	86203, PW: 86203
PSTN line number:	567-9728

IP phone

IP Address:	211.20.96.6
Caller ID	301



GW A Configuration

Step 1: Configuring the GW A IP address, subnet mask and gateway

Console>net setip 211.20.96.2 Console>net set mask 255.255.255.248 Console>net set gateway 211.20.96.1

Step 2: Configuring the GW A SIP setting

Console>set sipdns_ip 168.95.1.1 Console>set sipregadd 86101 500 1 siptest.ovislink.com.tw5060 86101 86101 Console>set sipregadd 86102 500 1 siptest.ovislink.com.tw5060 86102 86102 Console>set sip auto_reg on Console>set port 0 cid number 86101 Console>set port 1 cid number 86102 Console>config activate Console>config store

Step 3: DailPlan Setting

Console>atpm req



Console>atpm purge all Console>atpm aadd 86101 5 5 1 5 Console>atpm aadd 86102 5 5 1 5 Console>atpm aadd 9 1 16 11 1 Console>atpm aadd 301 3 3 12 0 Console>atpm hadd 1 2 1 2 Console>atpm hadd 1 2 1 2 Console>atpm hadd 12 2 12 Console>atpm hadd 12 2 12 Console>atpm dadd 1 port 0 Console>atpm dadd 2 port 1 Console>atpm dadd 2 port 1 Console>atpm dadd 12 sip 211.20.96.6 Console>atpm done Console>atpm done

Step 4: Reboot the Gateway

Console>net reset y



GW B Configuration

Step 1: Configuring the GW B IP address, subnet mask and gateway

Console>net set ip211.20.96.3 Console>net set mask 255.255.255.248 Console>net set gateway 211.20.96.1

Step 2: Configuring the GW B SIP setting

Console>set sipdns_ip168.95.1.1 Console>set sip reg add 86201 500 1 siptest.ovislink.com.tw5060 86201 86201 Console>set sip reg add 86202 500 1 siptest.ovislink.com.tw5060 86202 86202 Console>set sip reg add 86203 500 1 siptest.ovislink.com.tw5060 86203 86203 Console>set sip auto_reg on Console>set port 0 cid number 86201 Console>set port 2 cid number 86202 Console>set port 3 cid number 86203 Console>set coding all dtmf_relay off Console>config activate Console>config store

Step 3: DailPlan Setting



Console>atpm req Console>atpm purge all Console>atpm aadd 86201 5 5 1 5 Console>atpm aadd 86202 5 5 3 5 Console>atpm aadd 86203 5 5 3 5 Console>atpm aadd 9 1 16 11 1 Console>atpm aadd 301 3 3 12 0 Console>atpm hadd 1 2 1 Console>atpm hadd 3 2 3 4 Console>atpm hadd 11 2 11 Console>atpm hadd 12 2 12 Console>atpm dadd 1 port 0 Console>atpm dadd 3 port 2 Console>atpm dadd 4 port 3 Console>atpm dadd11 dns siptest.ovislink.com.tw Console>atpm dadd12 sip 211.20.96.6 Console>atpm done Console>atpm store

Step 4: Reboot the Gateway

Console>net reset y



Register Result

After reboot, if SIP ITG registered success, you can see below message

Password? nmmp_ssmu_activate sent registrar nmmp_ssmu_activate sent registrar The registration succeeded NMM: SIP register phone 86101 1 status: SUCCESS

Or you can key-in command "show sip reg" check ITG registered data:

Console>show sip reg Registrar 1: **Registered** reg_num:86101 registrar: sip.airlive.com 5060 expires: 500 name: 86101 passwd: 86101 if you register success , ITG will show "registered", otherwise it will show "UnRegistered".



How to Dial

Make a Call via the Proxy Server

GW A FXS call GW B FXS Dial '986202'or '986203'(Hunting)

GW A FXS call GW B FXO to PSTN

Dial '986201'get PSTN dial tone Dial PSTN #

GW B FXS call GW A FXS Dial '986101'or '986102'(Hunting)

PSTN # via GW B FXO call GW A FXS

From PSTN # Dial '5679728'get GW B dial tone Dial '986101'or '986102'(Hunting)

GW A or B FXS call IP Phone Dial 301

Make a Call to IP Phone Directly GW A or B FXS call IP Phone Dial 301