## How to Setup QOS in WN5000R?

1. Please login to the device and click QOS Setting, and click enable QOS

<b>Air Live</b>	Home   General Setup   Status	s   Tool	www.airlive.com WN-5000R 802.11n Wireless 11N Router
+ System + WAN + LAN + Wireless - QoS + NAT + Firewall	QOS 2 Quality of Service (QoS) refers to the c network traffic. The primary goal of QoS jitter and latency (required by some rea Also important is making sure that prov Penable QoS Total Download Bandwidth: Total Upload Bandwidth: Current QoS Table Priority Rule Name Add Edit Delete Selected	apability of a network to provide be is to provide priority including ded I-time and interactive traffic), and if iding priority for one or more flows Select V >> 0 Select V >> 0 Upload Bandwidth Dov Ban Delete All Move Up	tter service to selected licated bandwidth, controlled mproved loss characteristics. does not make other flows fail. kbits kbits vnload dwidth Select Move Down Reset

2. Please click in the Current QOS Table add.

<b>Air</b> Live	www.airlive.com WN-5000R Home   General Setup   Status   Tool 802.11n Wireless 11N Router
+ System + WAN + LAN + Wireless - QoS + NAT + Firewall	QOS This page allows users to add/modify the QoS rule's settings.
	Rule Name : Bandwidth : Download V Kbps guarantee V
	Local IP Address : Upload Download
	Remote IP Address :
	Protocol : TCP V Save Reset

## 3. Please insert the setting of the QOS.

Air Live	(www.airlive.com) WN-5000R Home   General Setup   Status   Tool 802.11n Wireless 11N Router
+ System + WAN + LAN + Wireless - QoS + NAT + Firewall	QOS This page allows users to add/modify the QoS rule's settings.
	Rule Name : Bandwidth : Download V Kbps guarantee V
	Local IP Address : quarantee max
	Local Port Range : Remote IP Address :
	Remote Port Range :
	Protocol : TCP V Save Reset

## 4.For example insert the http server qos setting and click save. To you're your setting.

<b>Air Live</b>	Www.airlive.com WN-5000R Home   General Setup   Status   Tool 802.11n Wireless 11N Router
+ System + WAN + LAN + Wireless - QoS + NAT + Firewall	<b>QOS</b> This page allows users to add/modify the QoS rule's settings.
	Rule Name : HTTP
	Bandwidth : Download 🕶 100 Kbps max 💌
	Local IP Address : 192.168.2.100 - 192.168.2.200
	Local Port Range : 80
	Remote IP Address : 0.0.0.0 -
	Remote Port Range : 80
	Protocol : TCP 💌
	Save