



BU-3028/BU-3028-IVS

3-Megapixel Smart Focus and
Zoom Bullet IPCAM /

3-Megapixel Smart Focus and
Zoom Bullet IPCAM with Video
Analytics

User's Manual



www.airlive.com



Copyright & Disclaimer

No part of this publication may be reproduced in any form or by any means, whether electronic, mechanical, photocopying, or recording without the written consent of OvisLink Corp.

OvisLink Corp. has made the best effort to ensure the accuracy of the information in this user's guide. However, we are not liable for the inaccuracies or errors in this guide. Please use with caution. All information is subject to change without notice

This product contains some codes from GPL. In compliance with GPL agreement, AirLive will publish the GPL codes on our website. Please go to www.airlive.com and go to the "Support->GPL" menu to download source code.

All Trademarks are properties of their respective holders.

FCC Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the A user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. For product available in the USA/Canada market, only channel 1~11 can be operated.

Selection of other channels is not possible.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

WEEE Marking Warning:

The crossed out wheeled bin indicates the product must not be disposed together with household waste. For the sake of the environment, the product should only be given to entities involved in the reception of waste electronic and electrical equipment. The lists of entities entitled to receive used equipment can be found on the websites of municipalities. Some components of devices such as external wiring, circuit boards and liquid crystal displays have a negative impact on the environment.



© 2009 OvisLink Corporation, All Rights Reserved

Table of Contents

1. Overview.....	1
1.1 Introduction.....	1
1.2 Features	2
1.3 Product Specification	3
1.4 System Requirement	6
2. Package Contents and Installation.....	7
2.1 Package Contents	7
2.2 Connections.....	7
2.3 Connect to IP Camera	9
3. Using IP Camera via Web Browser.....	12
3.1 Windows Web Browser.....	12
4. Operating IP Camera via iOS/Android device.....	13
4.1 Using IP Camera via iOS/Android device.....	13
5. Operating the Network Camera	16
5.1 Live View	17
5.2 Configuration	18
6. Configuration	19
6.1 Network	20
6.2 Video	26
6.3 Audio	34
6.4 Event	35
6.5 Storage	42
6.6 RS-485	43
6.7 System	46
6.8 Status	52
7. Appendix	54
A. Video Analytics (Only for BU-3028-IVS)	54
B. How to create App for Dropbox	62

1

Overview



This user's manual explains how to operate this camera from a computer. A user should read this manual completely and carefully before you operate the device.

1.1 Introduction

AirLive BU-3028/BU-3028-IVS is a high-end 3 Megapixels network camera with 3.5X smart focus motorized zoom lens which is designed for outdoor surveillance and security applications. This 3MP IP camera offers many improvements in backend 3.5X optical zoom adjustment and smart focus when comparing to conventional surveillance cameras. Users are able to view live video streaming over the Internet, and it is not only one of benefits for using AirLive BU-3028/BU-3028-IVS IP cameras.

It is also designed to offer high-performance surveillance by being equipped with PoE switch which allows power and data to be transmitted via a single Ethernet cable. This useful function provides an easier installation, lower cabling costs and allows placement of AirLive PoE cameras in locations without access to electrical source. With the IP66 and IK10 housing and cable through bracket, AirLive BU-3028/BU-3028-IVS suits for outdoor environments such as parking lot, backyard, campus and loading deck.

1.2 Features

This manual will illustrate the steps of how to setup and operate this IP camera, so you'll also soon be enjoying the benefits of these product features:

- ☐ 3~10.5mm Motorized Smart Focus and Zoom Lens
- ☐ 25m Smart IR LED
- ☐ Digital Video Stabilization
- ☐ IP66 and IK10 Protection with Anti-fog Front Cover
- ☐ Cable through Bracket
- ☐ 3-Megapixel CMOS Low Lux Sensor
- ☐ 25FPS at 2048x1536
- ☐ 802.3af PoE Port
- ☐ MicroSD Card Slot for Local Storage
- ☐ Two-Way Audio, DI/DO
- ☐ Clear Motion Technology for Moving Objects
- ☐ WDR Enhanced
- ☐ Compatible with OnVIF Standard
- ☐ IVS only for BU-3028-IVS
- ☐ Free 64-Channel Recording Software

1.3 Product Specification

Model		BU-3028/BU-3028-IVS
Camera	Camera Type	Bullet Type
	Max Resolution	2048x1536 1920x1080 (IVS Enable)
	Image Sensor	1/2.5" CMOS Sensor
	Lens Type	Smart Focus Motorized Zoom Lens
		3~10.5mm, F1.4
	Night Vision	Yes
	IR Distance	Smart IR 25m
	Minimum Illumination	0.2 Lux at F1.2 (Color)
	Mechanical IR-Cut Filter	Yes
	Auto Iris	None
	Viewing Angle	W: H : 80 °, V : 60 ° T: H : 33.7 °, V : 24.2 °
Video	Video Compression	H.264 / MPEG-4 / MJPEG
	Video Profile	Yes
	Resolution and Frame Rate	25 fps @ 2048 X 1536
		30 fps @ 1920 X 1080
		30 fps @ 1280 x 1024
		30 fps @ 1280 X 960
		30 fps @ 1280 X 720
		30 fps @ 720 X 480
		30 fps @ 640 X 480
		30 fps @ 320 X 240
		30fps @ 160 X 120
	Streaming	Streaming over UDP, TCP, or HTTP
		3GPP mobile view
		Configurable frame rate and bandwidth
		Support both CBR and VBR
	Region of Interest	Yes
	Image Processing	AE, AW, BLC,WDR,3DNR,Fog Compensation
		Brightness, Sharpness, Contrast, Saturation

		Mirror/Flip, NTSC/PAL
		Privacy Masks
		Text, time date and image OSD
	Digital Zoom	10x
Audio	Audio Encoder	G.711 / AMR (Only for 3GPP)
	Audio Streaming	Two-way
	Audio Input/Output	1 Line in, 1 Line out
Network	Ethernet	Ethernet (10/100 Base-T), RJ-45
	PoE	IEEE802.3af
	Supported Protocols	TCP/IP, IPV6, UDP, ICMP, DHCP, NTP, DNS, DDNS, SMTP, FTP, HTTP, HTTPs, Samba, PPPoE, UPnP, Bonjour, RTP, RTSP, RTCP, DLNA, ISCSI, OnVIF Profile S
	Security	Password protection
		IP filter, HTTPS encrypted data transmission
	Users	Up to 10 users simultaneous
LED and Button	Power LED	Yellow Color
	Link/Act. LED	Orange Color
	Reset Button	Reset to Factory Default (Push and Hold Over 5 Sec)
General	Network Processor	DSP Base
	System ROM	128M byte NAND Flash
	System RAM	128M byte DDR SDRAM
	Power Supply	DC 12V/1.0A
	Power Consumption	IR on: 11 Watts max. , IR off: 6 Watts max.
	Connector	RJ-45 10BaseT/100BaseTX
		Audio and Mic jack, DI/DO, DC jack, Ethernet/PoE
	Operating temperature and humidity	-20°C~55°C (-4°F~131°F), 20%~85%
	SD card slot	MicroSD
	Dimension	84 mm x 82mm x 193 mm

System Integration	Software	CamPro Express 64, CamPro Professional
		Search & Installation-IP Wizard II
	Event Triggers	BU-3028: Motion detection, External input via DI interface, Tamper Detection, Periodically Time, SD Card Read/Write Fail Detection, Network Disconnect, Audio Detection. BU-3028-IVS: Motion detection, External input via DI interface, Tamper Detection, Periodically Time, SD Card Read/Write Fail Detection, Network Disconnect, Audio Detection, Face Detection, iMotion Detection, Trip Zone, Object Counting, Face recognition, e-Fence.
	Motion Detection	3
	Event handler	FTP, Samba Server, SD card file upload, Google Drive, Dropbox
		E-mail notice
		HTTP and TCP notification
		DO (digital output) alarm
		Audio File Playback
	UPnP	Yes
	Application Programming Interface	OnVIF Profile S
		Open API for software integration
		SDK
	Video Buffer	Pre- and post- alarm buffering
	Alarm Triggers	BU-3028: Motion detection, External input via DI interface, Tamper Detection, Periodically Time, SD Card Read/Write Fail Detection, Network Disconnect, Audio Detection.

	Alarm Triggers	BU-3028-IVS: Motion detection, External input via DI interface, Tamper Detection, Periodically Time, SD Card Read/Write Fail Detection, Network Disconnect, Audio Detection, Face Detection, iMotion Detection, Trip Zone, Object Counting, Face recognition, e-Fence.
	Continuous recording	Yes
Viewing System	OS	Windows® XP, Vista, 7, 8
	Browser	Internet Explorer 8 or later; Apple Safari 2 or above; Firefox 2.00 or above; Google Chrome
	iOS/Android Device	With 3GPP player, CamPro Mobile for iOS/Android device
	Video Player	VLC, Quick Time, Real Player, Core Player

1.4 System Requirement

For normal operation and viewing of the network camera, it's recommended that your system meets these minimum requirements for proper operation:

Item	Requirements
CPU	Pentium-4 2.0 GHz or higher
VGA Monitor	Resolution 1024 x 768 or higher
RAM	1 GB or more
Operating System	Windows XP, Vista, 7, 8
Web Browser	Internet Explorer 7 or later; Apple Safari 2 or above; Firefox 2.00 or above; Google Chrome

Note: Please keep updating the latest Windows software and service package.
(Ex: Net Framework, Windows Media Player, Enhance ActiveX Security)

2

Package Contents and Installation

2.1 Package Contents

User can find the following items in the package as below:

1. AirLive BU-3028/BU-3028-IVS is the main element of the product.
2. Bundled CD includes AirLive IP Wizard II, CamPro Express64, Quick Start Guide, User Manual, and Video clip.
3. Quick Start Guide provides important information and instructions for installing this device.
4. Accessory Package (Screws / Plastic Anchors/ Power Adapter)

2.2 Connections

Power Source Requirement

This camera can work with 802.3af PoE switches. However, if you don't have the PoE switch, you can use a power adapter to provide power to camera.

Connector

There are various connectors of AirLive BU-3028/BU-3028-IVS as shown in the figures in next page. Please refer to the diagrams and tables for using of each connector.

1. DC Jack: The input power is DC 12V.
If you don't have the PoE switch, you can use a power adapter to provide power to camera.
2. PoE/RJ45 LAN Socket: Connect to PC or Hub/Switch.
This Ethernet port built N-Way protocol can detect or negotiate the transmission speed of the network automatically. Please use Category 5e cable to connect the Network Camera to a 100Mbps Fast Ethernet network switch or hub.




3. Alarm Digital I/O:

AirLive BU-3028/BU-3028-IVS supports RS-485, 2 digital alarm inputs and 1 digital alarm output. Please make sure the alarm connections are properly wired. Please refer to the pin definition table below.

PIN		SPECIFICATION
1	RS-485 D+	Compliant to RS-485
2	RS-485 D-	
3	Ground (Common)	GND
4	GPIO Out	Close circuit current maximum: 70mA AC or 100mA Output resistance: 30 ohm Open circuit voltage maximum: 240V AC or 350V DC
5	GPIO In #1	Action high voltage: 9~40 VDC
6	GPIO In #2	Dropout voltage: 0 VDC

4. Audio Output: 3.5mm phone jack.
5. Audio Input: 3.5mm MIC jack.
6. MicroSD Card Slot: MicroSD Card Slot allows you to insert a memory card for expansion of storage.



MicroSD card slot and reset button


7. Reset Button: This button is used to restore all the factory default settings. Sometimes, restarting the device will make the system back to a normal state.

2.3 Connect to IP Camera


1. Insert the bundled CD into your PC/Laptop.
2. Auto Run screen shows up, click "Install Software → AirLive IP Wizard II" to install the configuration tool.



3. After completed the installation, run the "Air Live IP Wizard II" to start to search the IP camera.



4. The entire detected IP camera will be listed out.



5. If the Camera's IP address is in the same IP segment as your LAN, select the founded IP Camera and double click on the item. Then, the default browser will show up and connect to the IP camera's Web automatically.

3

Using IP Camera via Web Browser

3.1 Windows Web Browser

1. Open your web browser and enter the IP address or host name of the IP camera in the Location / Address field of your browser.
2. Use the default account “**admin**” and default password “**airlive**”.



Note: The default user name “**admin**” and the password “**airlive**” are the default values. You can change them in the Account Menu. (Please check “System → Account”)

3. The monitor image will be displayed in your browser. In the left side of main window, you can configure the settings you want. For more details, please refer to the following chapters.

4

Operating IP Camera via iOS/Android device

4.1 Using IP Camera via iOS/Android device

You can access into your IP camera via the iOS/Android device. Please follow the setup steps below.


1. Download AirLive CamPro Mobile from APP store/Android market.




2. Execute the **AirLive CamPro Mobile** program




3. Click Setup button.



4. Setup page appears



5. Click Add button




The left screenshot shows the 'Device' screen with a list of devices. The 'Add' button is highlighted in a red box. The right screenshot shows the 'Device Edit' screen with the following fields:

- Device ID:
- Name: IPCam-1
- Model: <Not Selected>
- Address:
- HTTP Port: 80
- User Name: admin
- Password:

The 'Auto Search' button is highlighted in a red box.


6. Click Auto Search button and select the camera.




The left screenshot shows the 'Device Edit' screen with the 'Auto Search' button highlighted in a red box. The right screenshot shows the 'Device Edit' screen with a list of discovered cameras displayed in a scrollable view:

- BU-3025 - 192.168.0.13
- BU-3026-IVS - 192.168.0.103
- BU-3028-IVS - 192.168.1.100
- BU-720 - 192.168.0.14
- CW-720 - 192.168.0.48


7. Model, Address, HTTP Port info appear on the page.



8. Key-in Username and Password then click Save button.




9. If camera connects correctly, it will show blue icon.



10. The video appears on the main screen.







Note: The image is continuous snapshots, not video. Thus, live image can't be recorded here.





5

Operating the Network Camera

Start-up screen will be shown once you access into the IP camera.
In the left side, you can control Live View function as below:

HOME

Push to Talk

Zoom

W

T

Protocol

RTSP over UDP

Configuration

View Options

Streaming

H.264(2048x1536)

Video Output

Windows GDI

ActiveX Caching

150

Language

English


Digital Output

OFF

Max Viewers : 10

Current Viewers : 1

Please double click on the video image to go into Full Screen mode



Video Type : H.264

Resolution : 2048x1536

Bitrate : 320205

5.1 Live View

1. **Protocol:** Select the protocol type:
RTSP over UDP/ TCP/ RTSP over TCP/ RTSP over HTTP.
Please select **RTSP over HTTP** when connecting to the camera remotely.
2. **Configuration:** Click for configuring the detail camera settings.
3. **View Options:** The device supports multi-profile function for H.264, MPEG4 and JPEG simultaneously. User can choose the proper and/or preferred profile which is listed here.
4. **Language:** AirLive BU-3028/BU-3028-IVS provide multiple languages to meet customer's requirement.
5. **Digital Output:** Switch digital output interface on or off.
6. **2-Way Audio:** The device supports 2-way audio function. User can choose to enable or disable this function by toggling the icon below.



: Computer speaker function is disabled.



: Computer speaker function is enabled.





: Computer microphone function is disabled.






: Computer microphone function is enabled.




Volume: Click Speaker/ Microphone button to activate this function. Scroll the control bars to adjust the audio attribute.


7.  **Original size** /  **Preview Size:** Switches live image view between original size and preview size (smaller size).



8.   **Digital Zoom:** From 1X to 10X. Click  to full screen first.


Click  to enable this function. Click  to disable it.



Note: Digital zoom uses computer algorithm to enlarge the video and may lose some details.

9.  **Snapshot:** Take a snapshot. Browse the folder in your computer and save the image.

10.  **Record:** Click it to start recording an AVI file in the local storage. Press  to stop the recording process.

11.  **Zoom:** Adjust the control bar to change the zoom in & out and camera will focus automatically.

5.2 Configuration


Click "Configuration" for the camera detail settings. For more information, please refer to Chapter 6.

6

Configuration

Click the “**Configuration**” to display sub-menus included

Network / Video / Audio / Event / Storage / RS-485 / System / Status / Video Analytics.




The screenshot displays the AirLive configuration web interface. On the left, a sidebar menu shows 'Configuration' as the active section, with sub-menus for 'Back to Home', 'Network', 'Video', 'Audio', 'Event', 'Storage', 'RS-485', 'System', 'Status', and 'Video Analytics'. The 'Network' sub-menu is selected. The main content area is titled 'Network' and contains several tabs: 'General', 'UPnP/Bonjour/QoS', 'IP Filter', 'IP Notification', and 'iSCSI'. The 'General' tab is active, showing the 'LAN Interface' configuration. Under 'LAN Interface', there are three radio buttons: 'DHCP IPv4', 'DHCP IPv4/IPv6' (which is selected), and 'Static IPv4/IPv6'. Below these, there are input fields for 'IP Address(IPv4)' (containing '192.168.0.24'), 'IP Address(IPv6)', 'Prefix Length', 'Subnet Mask' (containing '255.255.255.0'), 'Gateway' (containing '192.168.0.254'), 'Primary DNS' (containing '192.168.0.254'), and 'Secondary DNS' (containing '0.0.0.0').

Note: Video Analytics function is only for BU-3028-IVS.

6.1 Network

1. General

 Network

General

UPnP/Bonjour/QoS

IP Filter

IP Notification

iSCSI

LAN Interface

☐ DHCP IPv4
 ☒ DHCP IPv4/IPv6
 ☐ Static IPv4/IPv6

IP Address(IPv4) : 192.168.0.73
 IP Address(IPv6) :
 Prefix Length :
 Subnet Mask : 255.255.255.0
 Gateway : 192.168.0.254
 Primary DNS : 192.168.0.254
 Secondary DNS : 0.0.0.0
 HTTP Port : 80
 RTSP Port : 554
 RTSP over HTTP Tunnel Port : 8554
 RTP Data Port : 5556

Multicast

☐ Enable Multicast
 Multicast Group Address : 239.128.1.99
 Multicast Video Port : 5560
 Multicast RTCP Video Port : 5561
 Multicast Audio Port : 5562
 Multicast RTCP Audio Port : 5563
 Multicast TTL[1~255] : 15

PPPoE

☐ Enable PPPoE
 User Name :
 Password :

DDNS

☐ Enable DDNS
 Provider : DynDNS.com
 Host Name :
 User Name :
 Password :

Apply

Cancel


- **LAN Interface:** This field allows you to setup the IP network protocol.
 - **DHCP IPv4:** Select this option when your network uses the DHCP server. When the camera starts up, it will be assigned an IP address from the DHCP server automatically.
 - **DHCP IPv4/IPv6:** DHCP for IPv6 enables the DHCP server to pass the configuration parameters (e.g. the IPv6 network addressed) to the IPv6 nodes, which offers the capability of automatic allocation of reusable network addresses and additional configuration flexibility. Select this option if your network supports DHCP IPv6 protocol. When the camera starts up, it will be assigned an IP address from the DHCP server automatically.
 - **Static IPv4/IPv6:** Select this option to assign the IP address to the camera directly. You can use “AirLive IP Wizard II” to obtain the related setting values.

IP Address (IPv4/IPv6)	Enter the IP address of the camera. The default setting is 192.168.1.100 .
Subnet Mask	Enter the Subnet Mask of the camera. The default setting is 255.255.255.0 .
Default Gateway	Enter the Default Gateway of the camera. The default setting is 192.168.1.254 .
Primary/Secondary DNS	DNS (Domain Name System) translates domain names into IP addresses. Enter the Primary and Secondary DNS provided by ISP.
HTTP Port	The default HTTP port is 80 .
RTSP Port	The default RTSP Port (Real Time Streaming Protocol) is 554 .
RTP Data Port	RTP (Real-time Transport Protocol) is a data transfer protocol defined to deliver live media to the clients at the same time, which defines the transmission of video and audio files in real time for Internet applications. The default RTP Data Port is 5556 .

- **Enable Multicast:** Select this option to enable the multicast function of the camera. Complete the following settings so that you can deliver information from your camera to multi receivers.
 - **Multicast Group Address:** Assign a category of IP addresses to receive the information from the camera.
 - **Multicast Video Port:** Assign a multicast port for video in the text box. The default port is **5560**.

- **Multicast RTCP Video Port:** Assign a multicast port for RTCP (real-time transport control protocol) video in the text box. The default port is **5561**.
 - **Multicast Audio Port:** Assign a multicast port for audio in the text box. The default port is **5562**.
 - **Multicast RTCP Audio Port:** Assign a multicast port for RTCP (real-time transport control protocol) audio in the text box. The default port is **5563**.
 - **Multicast TTL:** Set the value from 1 to 255. TTL (time to live) is used to specify the time to live in the IP header so that the system is able to decide whether or not the packet has been in the network too long and should be discarded.
- **Enable PPPoE:** Select this option when you use a direct connection via the ADSL modem. You need the User Name and Password of the PPPoE account to complete the setting. The camera will get an IP address from the ISP as starting up.
Note: Once the camera get an IP address from the ISP as starting up, it automatically sends a notification email to you. Therefore, when you select PPPoE as your connecting type, you have to set up the email or DDNS configuration in advance.
 - **Enable DDNS:** Select this option to enable DDNS service. With the Dynamic DNS feature, you can assign a fixed host and domain name to a dynamic Internet IP address. To set up the DDNS, select the Provider from the pull-down menu and then enter the required information in the Host Name, User Name and Password text boxes.
Note: You have to sign up for DDNS service with the service provider before configuring this feature.

2. UPnP/Bonjour/ QoS



Network

General | **UPnP/Bonjour/QoS** | IP Filter | IP Notification | iSCSI

UPnP

☒ Enable Discovery

☐ Enable Port Mapping ☒ Auto ☐ Manual

Bonjour

☒ Enable Discovery

QoS

☒ Enable QoS ☐ Audio ☒ Video ☐ Both

Video DSCP : (0-63)

Audio DSCP : (0-63)

Apply Cancel


- **UPnP:** The camera supports UPnP (Universal Plug and Play), which is a set of computer network protocols that enable the device-to-device interoperability. Select the **Enable Discovery** option to enable the feature.
In addition, it supports port auto mapping function so that you can access into the camera if it behind an NAT router or firewall. Select the **Enable Port Mapping** option to enable the feature.
- **Bonjour:** The devices with Bonjour will automatically broadcast their own services and listen for services being offered for the use of others. Select the **Enable Discovery** option, you can find the camera through the browser with Bonjour and no need to know the IP address.
The Apple Safari is already with Bonjour. You can download the complete Bonjour for Internet Explorer browser from Apple's website by visiting:
<http://www.apple.com/bonjour/>
- **QoS (quality of service):** It is the ability to provide different priority to different applications or data flows.
 - **Video DSCP:** Assign the DSCP (Differentiated services code point) of the stream video from the camera by setting the value from 0 to 63.
 - **Audio DSCP:** Assign the DSCP (Differentiated services code point) of the stream audio from the camera by setting the value from 0 to 63.

3. IP Filter

The IP Filter allows the administrator of the camera to restrict the users within a certain range of IP addresses to access into the camera. Select the **Enable Filter** option and assign the range of IP addresses that are allowed to access into the camera in the **Accept IP Address** field; or assign the range of IP addresses that are blocked to access into the camera in the **Deny IP Address** field.

For example, when you enter **192.168.0.50/192.168.0.80** in **Start/End IP Address** of **Accept IP Address** and then click **Add**, the user whose IP address located within **192.168.0.50 ~ 192.168.0.80** will be allowed to access into the camera. On the other hand, if you enter the IP range in **Start/End IP Address** of **Deny IP Address** and then click **Add**, the user whose IP address located within the range will not be allowed to access into the camera.

To remove the assigned range of IP addresses for IP Filter, select the setting in the **Accept/Deny IP List** and then click **Delete**.

 **Network**

General
UPnP/Bonjour/QoS
IP Filter
IP Notification
iSCSI

IP Filter

☐ Enable Filter

Accept IP Address:

Start IP Address :
End IP Address :

Add

Accept IP List :

Delete

Deny IP Address:

Start IP Address :
End IP Address :

Add


Deny IP List :

Delete

Apply
Cancel

4. IP Notification

To prevent from the IP address been changed, system is able to send out an alarm. Configure the email setting first if the function is enabled.

 **Network**

General
UPnP/Bonjour/QoS
IP Filter
IP Notification
iSCSI

IP Notification

☐ Notification(email)

Send To :
Subject :

☐ TCP Notification

TCP Server Address :
TCP Port :
Message :


☐ HTTP Notification

URL :
HTTP Port :
Login Name :
Login Password :

Apply
Cancel

- **Notification (email):** Select to enable this function.
Send To: Type the receiver's E-mail address.
Subject: Type the subject/title of the E-mail.
- **TCP Notification:** Select to enable this function.
TCP Server Address: Type the server name or the IP address of the TCP server.
TCP Port: Set port number of TCP server.
Message: The message will be sent to FTP server.
- **HTTP Notification:** Select to enable this function.
URL: Type the server name or the IP address of the HTTP server.
HTTP Port: Change it only when needed.
HTTP Login name: Type the user name for the HTTP server.
HTTP Login Password: Type the password for the HTTP server.

5. iSCSI



Network

General | UPnP/Bonjour/QoS | IP Filter | IP Notification | **iSCSI**

iSCSI

☐ Enable iSCSI ☒ Initiator

IP Address:


Port:

Apply Cancel

Enable the iSCSI and key-in server IP address and Port number. The disk of the server will be the storage in IP camera setting.

6.2 Video

1. Video Profile



Video Profile | Exposure | Image | WDR | Overlay | Focus | Privacy Mask

Intelligent Analysis Mode: ?

Video Stabilization:

Corridor Mode:

ROI: ?

Main Stream

Video Resolution:

Main Stream:

Frame Rate: ☐ Auto ☒ 30 fps

Rate Control: ☒ Video Quality (VBR)

☐ Bitrate (CBR) kbps ?

GOV:

Second Stream

☒ Enable Second Stream

Video Resolution:

Second Stream:

Video Quality:

Frame Rate: ☐ Auto ☒ 15 fps

Mobile View

Video Resolution:

☐ Disable

☐ 3GPP without Audio


☒ 3GPP with Audio

- **Intelligent Analysis Mode:** You can select Enable or Disable to switch the IVS function.
Note: This item will appear on BU-3028-IVS.
- **Video Stabilization:** Video Stabilization is a video enhancement technique which reduces the jitter in video caused due to camera shake. It is achieved by moving a sub-frame in the video frame in opposite direction to the camera movement.


- **Corridor Mode:** You can select Enable or Disable to switch the Corridor function.
Only support at 1080x1920 resolution. When enable Corridor mode, the Video stabilization, ROI will be disable.
- **ROI:** ROI means Region of Interest. When the main stream is set to High Resolution, user can select specified region for monitoring, this can save the bandwidth if there are too many collision on the network.
- **Main Stream & Second Stream:** It enables the encoder to deliver two totally independent streams of video, separately configured for different frame rates and video resolutions.
 - **Video Resolution:** Select the resolution that you want to see the image on screen from the pull-down menu. It supports several resolution as below:
 1. 2048 x 1536 (3M)
 2. 1920 x 1080 (1080P)
 3. 1280 x 1024 (SXGA)
 4. 1280 x 960 (960P)
 5. 1280 x 720 (720P)
 6. 720 x 480 (D1)
 7. 640 x 480 (VGA)
 8. 320 x 240 (QVGA)
 9. 176 x 144 (QCIF)You also need to select a proper **Frame Rate** setting.
In Intelligent Analysis Mode:
 1. 2048 x 1536 (3M)
 2. 1920 x 1080 (1080P)
 3. 1280 x 1024 (SXGA)
 4. 1280 x 960 (960P)
 5. 1280 x 720 (720P)Please select 1920x1080 or 1280x720 resolution when IVS is enable.
Please be noted that higher resolution and frame rate gets better video quality but larger network bandwidth.
 - **Main Stream / Second Stream:** Select the streaming format as H.264 (High/Main/Baseline Profile) / MPEG4 / MJPEG.
 - **Rate Control:** Set the proper image quality by selecting **Video Quality (VBR)** or **Bitrate (CBR)** and then select the desired settings from the pull-down menu.
Select Very Low, Low, Normal, High or Very High for VBR.
Input a bitrate range from 384Kbps to 6Mbps for CBR.
 - **GOV:** Set the GOV value by 1~100 frames.

- **Mobile View** (Not supported by MPEG4): The camera supports 3GPP specification. Select the **Disable** option to disable this feature. Otherwise, select **3GPP Without Audio** or **3GPP With Audio** to transfer the video clips without or with audio. If you use a mobile phone that supports 3GPP, you can also view the real-time streaming image captured by the camera on your phone (with the default player on the phone) by entering the RTSP link:
[rtsp://\(IP address of the camera\)/3gp](rtsp://(IP address of the camera)/3gp)
*Note: Your mobile phone and the service provider must support 3GPP function.
Please contact your service provider when you are failed to use this service.*

2. Exposure

 Video

Video Profile
Exposure
Image
WDR
Overlay
Focus
Privacy Masks



Exposure Setting

Exposure Mode
Auto

Others

Mode:
☐ indoor
☐ outdoor
☒ Auto

Auto White Balance:
Enable

IR-Cut:
☒ Auto
Photo Sensor
☐ AlwaysON
☐ AlwaysOFF

☐ Schedule
From: 00 : 00 To: 23 : 59 Day

Smart IR Mode:
Disable

ICR Delay Time:
5s

Apply
Cancel

- **Exposure Setting:** There are three options (Auto / Manual / Clear Motion). When you select Manual mode, you can adjust Exposure Value, Exposure Time and Gain value of the day and night mode.
 - **Mode:** There are three modes (Indoor / Outdoor / Auto) to fit your environment.
 - **Auto White Balance:** You can enable or disable the function.

- **IR-Cut:** The camera can automatically or manually remove the IR-cut filter to let IR light into the sensor during low light conditions.

Auto:

Photo Sensor: The camera automatically removes the filter based on the photo sensor.

Manual: User can use this function to determine the threshold, and the camera switches between day mode and night mode based on this specified threshold.

Always ON:

The camera switches on the IR cut filter at all times to block infrared light.

Always OFF:

The camera switches off the IR cut filter at all times for the sensor to accept infrared light.

Schedule:

The camera switches between day mode and night mode based on a specified schedule. Enter the start and end time for day mode.

- **Smart IR mode:** The camera can automatically adjust IR lighting intensity and ensures that the camera captures usable video in dark conditions, even when the object of interest is located close to the IR LEDs.
- **ICR Delay Time:** Select from 5s to 30s.

3. Image


● **Image Setting:**

- **Brightness:** Adjust the brightness level from 0~255.
- **Contrast:** Adjust the contrast level from 0~255.
- **Saturation:** Adjust the colors level from 0~255.
- **Sharpness:** Adjust the sharpness level from 0~255.
- Click **Default** to restore the default value.

Video

Video Profile
Exposure
Image
WDR
Overlay
Focus
Privacy Masks

Image Setting



Day Mode Setting

Brightness:
Contrast:
Saturation:
Sharpness:

128
128
128
128

[0..255]
[0..255]
[0..255]
[0..255]

Default

Night Mode Setting

Brightness:
Contrast:
Saturation:
Sharpness:

128
128
128
140

[0..255]
[0..255]
[0..255]
[0..255]

Default

Others

Mirror:
Power Line Frequency:

☐ Vertical
☐ Horizontal


☒ NTSC/60Hz
☐ PAL/50Hz

Apply
Cancel

● Others:


- **Mirror:** Select **Vertical** to mirror the image vertically, or select **Horizontal** to mirror the image horizontally.
- **Power Line Frequency:** Select the proper frequency according to the camera's location to reduce the flicker: **NTSC/60Hz** or **PAL/50Hz**.

4. WDR



- **WDR Setting:** WDR is intended to provide clear images even under backlighting, where the intensity of illumination varies a lot.
- **BLC Setting:** Backlight compensation can get ideal exposure of object which is in front of the strong luminance background
- **Advance:**
 - Digital Noise Reduction: A digital filter designed to reduce visible noise for improving visibility of images.
 - Fog Compensation: Improve visibility of images in fog or smoke by using the Fog compensation function.

5. **Overlay:** This option is used to set the image overlay and mask feature of the camera.



Video

Video Profile | Exposure | Image | WDR | **Overlay** | Focus | Privacy Masks

Overlay Setting

☐ Enable Time Stamp ☐ Transparent

☐ Enable Text Display BU-3028 ?

☐ Enable Image Overlay ☐ Transparent

☒ Default Logo


☐ User Define Image

Bitmap/JPG/JPEG Only Max. Size: 160x128


- **Enable Time Stamp:** Select this option to display the date & time information on the live view image.
- **Enable Text Display:** Select this option and enter your heading text in the box to display the text information on the live view image.
- **Enable Image Overlay:** Select **Default Logo** or **User Define Image** to display the image overlay on the live view image.
You can set the displayed image in transparent mode by selecting the **Transparent** option and select the background color as white or black.
When you select **User Define Image**, you can click **Browse** to select the image file from your computer and then click **Update** to apply the setting.

Note: JPG/JPEG file with maximum 65536 bytes.


- 6. Focus:** Focus (**Smart Focus**) is applicable to Network Cameras that are equipped with stepping motor lens. The automated focus adjustment function eliminates the needs to physically adjust camera focus. In an outdoor deployment consisting of a large number of cameras, the auto focus function can be very helpful when these cameras become out of focus after days or weeks of operation. The Smart Focus module provides a solution to the difficulties of adjusting focus after the camera has been installed and is in use. The camera determines the best focus value, and displays this on-screen as well. The ability to fine-tune focus remotely is particularly desirable for surveillance cameras because they are often installed in locations that are difficult to access. It allows administrators to easily make focus adjustments on cameras using lenses equipped with stepper motors via the camera's browser interface.



- **Zoom:** Use the **Zoom** slide bar to find an optimal view of the area of interest where you want to adjust its focus. Click and drag the pointer to rapidly adjust the zoom ratio. The **Focus** pointer moves with the Zoom pointer correspondingly. After a short while, the clearest image obtained should be displayed and the optimal. The **Zoom** slide bar is the same as that on the home page.
- 7. Privacy Masks:** Click Privacy Mask to open the settings page. On this page, user can block out sensitive zones to address privacy concerns. User can use the mouse cursor to size and drag-drop the window, which is recommended to be at least twice the size of the object (height and width) you want to cover. Up to 4 private mask windows can be set up on the same screen.



6.3 Audio



1. Microphone:

- **Enable Microphone:** Select the option to enable the camera's audio in function, so that you can receive the on-site sound and voice from the camera.

2. Speaker


- **Enable Speaker:** Select the option to enable the camera's audio out function, so that the connected speaker can play the sound and voice through the camera.

3. Recording File:

During an event action, you can upload one audio file in WAV (mono, 8KHZ, <100KB in size) for playback.

6.4 Event

1. Event

 **Event**

Event | Event Schedule | Motion Detection | Audio Detection | Tamper Detection

Media Format

- ☐ One Snapshot
- ☒ H.264 Video

Pre Event: Second

 Post Event: Second

FTP Server
☐ Enable

Mail Server
☐ Enable SMTP

Samba Server
☐ Enable

TCP Server
☐ Enable

HTTP Server
☐ Enable

Dropbox
☐ Enable [Create App](#)


- **Media Format:** Select **One Snapshot** to send the alarm message with one still image captured by the camera, or select **H264 Video** to send the alarm message with one video clip recorded by the camera.
You can set the attachment that is captured in **Pre Event** or **Post Event** time when the event has been triggered.
- **FTP Server:** Select “Enable” to enable the FTP server function.
 - **FTP Server:** Enter the IP address of the target FTP server.
 - **User Name:** Enter the user name to login into the FTP server.
 - **Password:** Enter the password to login into the FTP server
 - **File Path Name:** Enter the port number used for the FTP server.
 - **Test FTP:** You can test the FTP server function first here.
Note: Due to the network environment, the camera may not upload number of images that you set.
- **Mail Server:** Select “Enable” to enable the Mail server function.
 - **SMTP Mail Server:** Enter the mail server address. For example, mymail.com.
 - **Port:** Assign the SMTP port in the text box. The default SMTP port is **25**.
 - **Sender Email Address:** Enter the email address of the user who will send the email. For example, airlive@mymail.com.
 - **Receiver #1/#2 Email Address:** Enter the first/second email address of the user who will receive the email.
 - **Subject:** Enter the subject of the message for the event.
 - **Authentication:** Select the option according to the mail server configuration.
 - **User Name:** Enter the user name to login the mail server.
 - **Password:** Enter the password to login the mail server.
 - **Test SMTP:** When done, click the button to test the SMTP server function.
 - **Requires SSL Encryption:** If the mail server requires an encrypted connection, you should select the SSL option.
 - **STARTTLS:** Select it if the server needs the STARTTLS encryption.
Note: Due to the network environment, the camera may not upload number of images that you set.
- **Samba Event Server:** Select “Enable” to enable the Network Storage server for the camera.
 - **Samba Server Address:** Enter the IP address of the Network Storage server.
 - **Path:** Assign the path for uploading the files on the Network Storage server.
 - **User Name:** Enter the user name to login into the Network Storage server.
 - **Password:** Enter the password to login into the Network Storage server.

- **Test SMB:** When done, click the button to test the network storage server function.
Note: The recorded video files in Network Storage are enclosed by MP4/AVI format without audio.

- **TCP Server:** Select “**Enable**” to enable the TCP Server function.
 - **TCP Server Address:** Enter the TCP server address.
 - **TCP Port:** 80. Revise it only needed.
 - **Message:** Enter the message here.
 - **Test TCP:** Click to test the TCP server function.
- **HTTP Server:** Select “**Enable**” to enable the TCP Server function.
 - **URL:** Enter the URL path of the HTTP server.
 - **HTTP Port:** 80. Revise it only needed.
 - **Login Name:** Enter the login name of the HTTP server.
 - **Login Password:** Enter the login password of the HTTP server.
 - **Message:** Enter the message here.
 - **Test HTTP:** Click to test the HTTP server function.
- **Dropbox:** Please refer the **Appendix B**

2. Event Schedule

Click “Add” for more detail settings.



The screenshot shows a web interface for configuring events. At the top, there's a header with a bell icon and the word "Event". Below this is a navigation bar with five tabs: "Event", "Event Schedule" (which is highlighted in blue), "Motion Detection", "Audio Detection", and "Tamper Detection". The main content area is titled "Event List" and contains a table with two columns: "Event Name" and "Status". Below the table, there are three buttons: "Add", "Edit", and "Delete".

- Follow the steps below to set up the Event Schedule for the camera:
 1. Select “**Enable**” and enter the **Event Name**.
 2. **Schedule:** Select to always trigger the event or on specific time period and date.
 3. Select the **Trigger** by: **Motion Detection / Digital Input 1 / Digital Input 2 / Tamper Detection / Video Analytics / Periodically time/ SD Card Read/Write Fail Detection / Network Disconnect / Audio Detection**.
 4. **Action:** Select the trigger method.
 - **Enable FTP:** The camera will upload the attachment to FTP when triggered.
 - **Enable EMAIL:** The camera will send the attachment to the assigned receiver when triggered.
 - **Enable Samba:** The camera will transfer the attachment to the network storage when triggered.

- **Enable SD CARD:** Image will be saved into local MicroSD Card when triggered.
- **Enable TCP:** The camera will send instant message when triggered.
- **Enable HTTP:** Camera will send the attachment to HTTP server.
- **Google Drive:** The camera will send the attachment to the Google Drive when triggered.
- **Trigger digital output:** The camera will trigger the connected device on the camera's output for 1~60 seconds.
- **Audio File Playback:** Playback a recorded audio file when triggered.
- **Modify/Delete:** To change/remove the event profile, select the file on the list and click **Modify/Delete**.

Note: To enable the FTP/Email/Samba/TCP/HTTP services, the required settings of must be completed in Event section.

Configuration

Back to Home

Network
Video
Audio
Event
Storage
RS-485
System
Status
Video Analytics

Event

Event ScheduleMotion DetectionAudio DetectionTamper Detection

Media Format

☐ One Snapshot
☒ H.264 Video

Pre Event: 0 Second
Post Event: 5 Second

FTP Server

☐ Enable

Mail Server

☐ Enable SMTP

Samba Server

☐ Enable

TCP Server

☐ Enable

HTTP Server

☐ Enable

Google Drive


☐ Enable

Apply

Cancel

3. Motion Detection


The Motion Detection option contains the commands and settings that allow you to enable and set up the motion detection feature of the camera. The camera provides three detecting areas.



- Follow the steps below to set up the Motion Detection function for the camera:
 1. Select **Enable Motion Detection**.
 2. **Window 1/2/3**: When the detecting area is enabled, you can use the mouse to move the detecting area and change the coverage.
 3. Set the **Percentage** and **Sensitivity** (1~99) for detecting motion to record video.
 4. When done, click **Apply** to save the settings and activate the motion detection function.


4. Audio Detection:

- **Audio Detection**: Select to enable or disable the audio detection function.
- **Audio Alarm Level**: The higher level means need higher volume to trigger the event.



5. Tamper Detection


Camera Tamper Detection (CTD) detects tampering events in surveillance cameras that may compromise the integrity of the video content. Examples of camera tampering include obstructing the lens with paint or a foreign object, adjusting the lens' focus or aperture settings, pointing the camera in a different direction, and turning off the lights (if indoors with no major change in ambient illumination expected). CTD can tolerate the effects of automatic camera gain, camera shaking that causes mild image jitter (less than +/- 4 pixels in any direction), and dimly lit scenes.



- Select ON/OFF to enable/disable the Tamper Detection.
- Select **Sensitivity** to set the sensitivity level.
The higher the sensitivity, detects the minutest tampering attempts.
- Select **Reset Time**. Once a tampering is detected, the camera will resume a normal operating after a certain stability time (**Reset Time**) during which no detection will be performed.
- Select **Alarm Type** to specify the activation condition.
- **Statistics Chart Display**: You can see the test result of alarm type here.

6.5 Storage

1. Recording



The screenshot shows the 'Recording' configuration window. It has two tabs: 'Recording' (selected) and 'Recording List'. The 'Recording' tab contains two sections: 'Recording' and 'Schedule'.

Recording Section:

- ☐ Enable Recording
- ☒ NAS/File Server
- ☐ SD CARD
- ☐ iSCSI
-
- NAS/File Server :
- Upload Path : /
- Login Name :
- Password :
- Maximum Size of Each File : MB
- ☒ Enable adding timestamp to files

Schedule Section:

- ☒ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☒ Sat
- Time:
 - ☒ Always
 - ☐ From : To : hh:mm

At the bottom, there are 'Apply' and 'Cancel' buttons.

- **Recording:** Select the option to enable the recording to storage function.
 - **NAS/File Server:** Enter the IP address of the Network Storage/CIFS server.
 - **Upload Path:** Assign the path for uploading the files on the Network Storage/CIFS server.
 - **Login Name:** Enter the user name to login into the Network Storage/CIFS server.
 - **Password:** Enter the password to login into the Network Storage/CIFS server.


- **Maximum Size of Each File:** This option allows you to limit the file size to be uploaded to the server.
- **Timestamp:** Select this option to add the date & time information on the attachment.
- **Schedule:**
 - **NAS/File Server:** Enter the IP address of the Network Storage/CIFS server.
- **Schedule:** Select “**Always**” to enable recording continuously or select specific time period and date to record. When done, click **Apply** to save the settings.

2. Recording List

This page shows the files list information. User may play or delete the selected file.

Note: Please remember to insert a MicroSD card before you start to use this function.

You can format MicroSD card in System=> Maintenance.



6.6 RS-485


1. RS-485 Setting

The RS-485 option provides the control settings for external device through the I/O port. Select Enable RS-485 and complete the required settings to activate the RS-485 function of the camera.

- **Use Pelco-D:** Select this option and then select an Address. When you enable the RS-485 function of the camera, you will be able to use the RS-485 Buttons on the live view screen to control the camera.

- **Use Custom Protocol:** Select this option to configure the commands protocol manually. When you select this option, you need to complete the required settings of Port Setting.

You can click Test to test each command that you have assigned. In the Extended Command 1~5 string boxes, you can customize more buttons and settings for your needs. Please note that the setting values in the Command Name string boxes should be from the connected external device (please refer to the manual of the connected device).



Configuration

Back to Home

Network
Video
Audio
Event
Storage
RS-485
System
Status
Video Analytics

RS-485

RS-485 Settings **RS-485 PTZ**

RS-485

☐ Enable RS-485

☒ Use Pelco-D ☐ Use Pelco-P

Address: (Pelco-D:0~254 Pelco-P:1~32)

☐ Use Custom Protocol

Port Setting

Baud Rate:

Data Bits:

Parity:

Stop Bit:

2. RS-485>>RS-485 PTZ

You can enable RS-485 PTZ function when you have Pan/Tilt Head.

Configuration

Back to Home

Network
Video
Audio
Event
Storage
RS-485
System
Status
Video Analytics


RS-485

RS-485 Settings
RS-485 PTZ

RS-485 PTZ

☐ Enable RS-485 PTZ

PTZ Preset



Preset:
Home
Go To
Description:
Home
Submit


PAN Speed:
1

TILT Speed:
1

Apply
Cancel

6.7 System

The System menu contains sub-menus as below. When completed, click **Apply** to save the settings.

 **System**

Device Settings

Account

Management Ports

Firmware

Maintenance

DIPS

DIPS (Dynamic IP Service):
☒ Enable
☐ Disable

Device ID (for DIPS):

Information

Camera Name:

Location:

Indication LED

Control:
☒ ON
☐ OFF

Date & Time

Camera Date & Time:
03/16/2015 16:34:14

TimeZone:

☐ DayLight Saving

☐ Don't Modify

☒ Synchronize with NTP Server

NTP Server Address:

Update Interval:

☐ Manual


☐ Synchronize with PC

1. Device Settings

- **DIPS:**
 - **DIPS (Dynamic IP Service):** To enable or disable the DIPS® (Dynamic IP Service) function.
 - **Device ID (for DIPS):** It's a unique number of each device for identification.
- **Information:** This item allows you to assign the camera name and location information.
 - **Camera Name:** Enter a descriptive name for the camera, which is helpful to identify the camera easily while multiple cameras are connected within the network.
 - **Location:** Enter a descriptive name for the location where is monitored by the camera.
- **Indication LED:** This item allows you to set the LED illumination as desired. The available options include: **ON** and **OFF**.
- **Date and Time:** Enter the correct date and time for the system.
 - **Camera Date & Time:** It shows the current date and time.
 - **Time Zone:** Select the proper time zone for the region from the pull-down menu.
 - **Day Light Saving:** Select this option if the Daylight Saving Time is used in your location.

Daylight Saving means a period from late spring to early fall, and during the period many countries will set their clocks ahead of normal local time by one hour to give more daytime light in the evening.
 - **Don't Modify:** Select this option to set the date and time as system's default settings.
 - **Synchronize with NTP Server:** Select this option and the time will be synchronized with the NTP Server. You need to enter the **NTP Server Address** of the server and set the **Update Interval**.
 - **Manual:** Select this option to set the date and time manually.
 - **Synchronize with PC:** Select this option and the date & time settings of the camera will be synchronized with the connected computer.

2. Account

 System

Device Settings
 Account
 Management Ports
 Firmware
 Maintenance

Viewer Login
 ☐ Anonymous
 ☒ Only users in database
 Save

Admin

Password:

 Confirm Password:

 Modify

Users

User Name :

 Password :

 Confirm Password:

 User List :

 Add
 Delete

Guest

User Name :

 Password :

 Confirm Password:

 Guest List :

 Add
 Delete

- **Viewer Login:** Anonymous means user can login without user name and password. Or select “**Only users in database**” to limit the authentication.
- **Admin:** To prevent unauthorized access to the camera’s Web Configuration, you are strongly recommend to change the default administrator password. Type the administrator password twice and then click **Modify** to set and confirm the password.
- **Users**
 - **User Name/Password/Confirm Password:** Enter the user’s name you want to add to use the camera. Then, enter the password twice for the new user. When done, click Add to add the new user for the camera.


- **User List:** Display the existing users of the camera. To delete a user, select the one you want to delete and click **Delete**.

- **Guest**

- **User Name/Password/Confirm Password:** Enter the user's name you want to add to use the camera. Then, enter the password twice for the new user. When done, click Add to add the new user for the camera.
- **Guest List:** Display the existing guests of the camera. To delete a guest, select the one you want to delete and click **Delete**.


Note: The "Users" can access the camera and control the Function buttons of the camera's Web Configuration; the "Guest" can only view the live view image from the Main screen of the Web Configuration while accessing the camera. Only the "Admin" is allowed to configure the camera through the Web Configuration.

3. Management Ports



- **HTTPS:** Select the **Enable HTTPS** option to enable HTTPS which is a secure protocol to provide authenticated and encrypted communication within your network.
- **HTTPS Port:** Assign a HTTPS port in the text box. The default HTTPS port is **443**.

4. Firmware




- **Update Firmware:** You can upgrade the firmware for your camera once you obtained a latest version of firmware.
 - **Current Firmware Version:** It displays the current firmware version.
 - **Update:** Click **Browse** to locate the firmware file and then click **Update**.

Warning!!!

The download firmware procedure cannot be interrupted. If the power and/or network connection are broken during the download procedure, it might possibly cause serious damage to the device. Strongly suggest that DO NOT upgrade firmware via Wireless LAN due to high error rate possibly and don't allow any other clients to access this unit during updating procedure. Be aware that you should not turn off the power during updating the firmware and wait for finish message. Furthermore, the firmware upgrade procedure always is risk and do not try to upgrade new firmware if it's not necessary.

5. Maintenance

 System

Device Settings
 Account
 Management Ports
 Firmware
 Maintenance

Factory Reset

Factory reset will restore all the settings to factory default

Reset

Factory reset will restore all the settings to factory default (Excluding Network Setting and Account)

Reset

System rebooted

Reboot

Configuration Backup

Backup

Backup To SD CARD Device

Configuration Restore

Select the configuration file to restore:

Browse...
 Restore
 Restore From SD CARD Device

Format

SD Card


- **Factory Reset:** Click **Reset** to restore all factory default settings for the camera.
- **System rebooted:** Click **Reboot** to restart the camera just like turning the device off and on. The camera configuration will be retained after rebooting.
- **Configuration Backup:** You can save your camera configuration as a backup file on your computer. Whenever you want to resume the original settings, you can restore them by retrieving the backup file.
 - **Backup:** Click the button to save the current configuration of the camera.
 - **Backup to MicroSD CARD Device:** Click to save the configuration file to MicroSD card.
- **Configuration Restore:** click **Browse** to locate the backup file on your PC and then click **Restore**.
 - **Restore From MicroSD CARD Device:** Restore the backup file from MicroSD card.
- **Format:** Click to format the MicroSD card.

6.8 Status

The Status menu shows the current status of the camera, including the basic information, audio/video settings, networking configuration, and system logs.

1. Basic

It provides the basic information as above.




The screenshot shows the 'Status' menu with the 'Basic' tab selected. The 'Basic' section displays the following information:

Camera Name:	BU-3028-IVS
Firmware version:	build: 1.27
MAC:	00:0C:0C:A0:32:09
Camera Date & Time:	03/16/2015 16:38:07

2. Audio/Video


It provides the information including H.264/MJPEG/Mobile View/Audio as below.



The screenshot shows the 'Status' menu with the 'Audio/Video' tab selected. The 'Audio/Video' section displays the following information:

Section	Parameter	Value
H.264	Video Resolution:	1920x1080 (1080P)
	Video Quality:	Very High
	Frame Rate:	25 fps
MJPEG	Video Resolution:	640x480 (VGA)
	Video Quality:	Very High
	Frame Rate:	10 fps
Mobile View	3GPP Enable:	3GPP with Audio
Audio	Microphone In:	Disable
	Microphone Gain:	+10 dB
	Speaker Out:	Disable


3. **Network:** It provides the information including IP/LAN as below.



The screenshot shows the 'Status' page with the 'Network' tab selected. Under the 'Wired Interface' section, the following network configuration is displayed:

IP MODE:	DHCP IPv4/IPv6
IP Address(IPv4):	192.168.0.212
IP Address(IPv6):	
Subnet Mask:	255.255.255.0
Gateway:	192.168.0.254
Primary DNS:	168.95.1.1
Secondary DNS:	8.8.8.8
MAC:	00:0C:0C:A0:32:09

4. **System Log:** It provides the log information as below.



The screenshot shows the 'Status' page with the 'System Log' tab selected. It contains two main sections: 'Syslog' and 'Log List'.

Syslog Section:

- ☐ Enable remote log
- IP Address:
- Port:
-

Log List Section:

Item	Date and Time	Event
1.	03/16/2015 15:28:13	admin login on 192.168.0.65
2.	03/16/2015 15:15:59	admin login on 192.168.0.65
3.	03/16/2015 14:54:24	admin login on 192.168.0.65
4.	03/16/2015 14:54:00	admin login on 192.168.0.59
5.	03/16/2015 14:50:44	admin login on 192.168.0.65
6.	03/16/2015 14:47:56	Sync with NTP server: [2015/03/16 14:47:56]
7.	03/16/2015 14:47:50	[RTSP SERVER]:Start one session<192.168.0.212>
8.	03/16/2015 14:47:49	[RTSP SERVER]:Stop one session<192.168.0.212>

Navigation buttons:

- **Enable remote log:** Enter the IP address to enable the remote log function.

7

Appendix

A. Video Analytics (Only for BU-3028-IVS)

BU-3028-IVS provides multiple intelligent video analytics that helps you to save your human resources and reach the goal of automatic surveillance.

Please go to **Configuration→Video Analytics** to experience the entire IVS function.

Note: Only one Video Analytics function can be executed at same time.


When using Video Analytics, we will recommend you to use 2-Megapixel resolution for best performance. If 3-Megapixel resolution is selected, only Face Detection will be available.

A.1 Face Detection:

Face detection is a precise feature which needs highly accurate rate of recognition on human faces only. The software is able to count how many faces in the image and also highlights those faces simultaneously so the administrator will be easier to look in details on each face at specific environment.

Video Analytics

Face Detection



03/16/2015 17:11:09

Sensitivity:

75%

Event Conditions:

Trigger Quantity

1

Interval

User Define
1
SEC

Set Event Action

Detection Result Overlay:

OFF
Privacy Mask
Rectangle

Calibration (Min. Face Size)

Show

Face Enhancement:

OFF
ON

Image Capture

Media Format

One Snapshot
H.264 Video

Pre Event
0
Post Event
5

Save To SD Card
Test SD Card

Statistics Record

Statistics Record

Export Mode

Manual
Auto Daily Report

Statistics Period

By minute

Export Data

From

Month
Day
Hour
Minute

Jan
1
0
0

To

Month
Day
Hour
Minute

Dec
31
23
59

Export
Save To SD Card
Reset

Statistics Chart Display

- **Sensitivity:** Adjust sensitivity 0~100%, the higher sensitivity means more precisely and detailed face detection.
- **Event Conditions:** Once you want to change the trigger condition, you have to select the event interval by NONE, Daily, Hourly or User Define and Quantity. For example, if you set Trigger Quantity for 5 people and interval with “1 Minute”, IP Camera detects 5 faces will trigger alarm. In the following one minute, camera won't trigger alarm even though there are more than 5 faces are detected. After one minute, camera will trigger alarm again if it detects 5 faces again.
- **Set Event Action:** Go to the Event Schedule to Add or Edit the IVS event.
- **Detection Result Overlay:** Select OFF, Privacy Mask or Rectangle to be shown on the face when any face has been detected.

55

AirLive BU-3028/BU-3028-IVS User's Manual


- **Calibration (Min. Face Size):** Face detection requires the min. face size is 20x20 pixels, so you can use this for reference.
- **Face Enhancement:** Enable this function for more accuracy.
- **Image Capture:** Enable this function to save the image to Samba server or MicroSD card.

Note: When you change the media format, it will effect all the exsisted events.

- **Statistics Record:** This function can record how many faces have been detected. You can configure your camera in different ways to generate the statistics you required and statistic data can be exported in csv format file.
 - Select **Auto**, camera can send yesterday report to Samba server or FTP server automatically.
 - Select **Statistics Period** to specify the period you want the data for.
 - Select the range to export the data or press "Reset" to delete it.
- **Statistics Chart Display:** Enable this to see the detection result by chart.

A.2 Face Recognition:

The key feature of Face Recognition is to recognize faces for access control or any suspicious persons in camera which match the database. You can save up to 10 face images to the AirLive BU-3028-IVS for recognition, so when the camera catch the face which match the database, the camera will trigger related output devices by necessary reaction.



The screenshot displays the 'Video Analytics' configuration page in the AirLive web interface. On the left is a navigation menu with options: Configuration, Back to Home, Network, Video, Audio, Event, Storage, RS-485, System, Status, and Video Analytics (highlighted). The main content area is titled 'Video Analytics' and contains two sections: 'Face Recognition' and 'Face Database'.

Face Recognition Section:


- Face Recognition:** A dropdown menu with a help icon.
- Trigger Interval:** A dropdown menu set to '5 sec' with a help icon.
- Recognition Result Overlay:** A dropdown menu set to 'Disable'.
- Confidence Level:** A slider bar set to 75%.
- Set Event Action:** A button.
- Latest Recognized User:** A box showing a face image of 'USER1' with the timestamp '2015-03-23 14:30:58'.


Face Database Section:


- Face Database:** A box showing a live video feed of a person's face with a yellow bounding box around it.
- Buttons:** Register, Edit Users Database, Backup To SD CARD Device, Restore From SD CARD Device, Backup, and Restore.
- New Registered User:** A box showing a face image of 'USER1' with 'Change' and 'Delete' buttons.


- Select proper alarm time in **Trigger Interval**.
- Select to Enable/Disable the overlay in **Recognition Result Overlay**. All the detected face will be shown on the live view screen.
- Select **Confidence Level** to set the confidence threshold when compared to the faces in the database. Confidence level 40~60 is recommended.
- **Set Event Action**: Go to the Event Schedule to Add or Edit the IVS event.
- **Register** function supports memorizing up to **10** results of face recognition into the database. Also you can select to edit the database, backup to or restore from the MicroSD card device.
- **Edit Users Database**: You can edit the registered database here. (See below)


Video Analytics
Face Recognition
Edit Users Database
Edit Users Database
Delete All
Registered Users


USER1
Change
Delete



USER2
Change
Delete



USER3
Change
Delete



USER5
Change
Delete



USER6
Change
Delete


USER7
Change
Delete


USER8
Change
Delete


USER9
Change
Delete



USER10
Change
Delete


USER11
Change
Delete


Apply
Cancel
Default

A.3 iMotion Detection (Intelligent Motion Detection)

Intelligent Motion Detection is able to increase the accuracy of motion detection and also provides more flexible setting with polygon for the zones. Any moving object in the zone will trigger this alarm. Objects must move and stay within the boundary for at least 100 ms.




- Select **Sensitivity** to set the detection sensitivity level. Higher sensitivity will make it easier to detect and less objects missing, but more misjudgments.
- Select **People / Vehicles / Anything** as the detected objects.
- Select **Calibration (People or Vehicle Object Sizes)**. The minimum and maximum boundary of objects can be specified to improve the detection accuracy. The width and length values must be at least 6 pixels. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Min. Size of Calibration:** The width and length values must be 6 pixels at least. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Max. Size of Calibration:** It has to be larger than the minimum size and half the frame size is the most.
 - Go to the Event Schedule to Add or Edit the IVS event in the **Set Event Action**.
 - Up to **4** zones can be specified when click the **Add Zone** function. Left click to add the point and **15** points at most can be used in each zone.
 - Select **Delete Zone/All** to delete the zones
 - Select **Enable/Disable** to allow the trigger or not.

A.4 Trip Zone

The Trip Zone is an area protection based on two virtual areas with a line in center. Any object moves across the line within 0.5 second at least will trigger the alarm and send out an alert. It can be set to detect one direction or both directions. It is very useful to some surveillance environments like walls, railroad platform, parking lot entrance or any intersection where needs to monitor the “Against Traffic”.

Video Analytics

Trip Zone



II

Hide Rule

☐ Statistics Chart Display

Trip Zone Settings

Sensitivity:
MODERATE

Detect:
☐ People
☐ Vehicles
☒ Anything

Calibration:
☐ People
☐ Vehicles

Event Conditions:
Interval
User Define
1
SEC

Set Event Action

Zone Settings

Edit Mode
☒ Rotate Mode
☐ Transform Mode

Directionality
☐ Bi-Directional
☐ Zone 1 to 2
☐ Zone 2 to 1

Apply
Cancel
Default

- Select **Sensitivity** to set the detection sensitivity level. Higher sensitivity will make it easier to detect and less objects missing, but more misjudgments.
- Select **People / Vehicles / Anything** as the detected objects.
- Select **Calibration (People or Vehicle Object Sizes)**. The minimum and maximum boundary of objects can be specified to improve the detection accuracy. If any false detection caused by smaller objects, you can try to increase the minimum size.
- In **Event Conditions**, you can specify the minimum time interval and quantity (500 at most) for each alarm. And go add or edit the IVS event in the **Set Event Action**.
- Select **Rotate Mode** or **Transform Mode** in **Edit Mode**.
 - **Rotate Mode**: User can rotate the zone at will.
 - **Transform Mode**: User can drag the point of the zone to any shape.
- **Directionality**: User can select the detected moving direction from one to another or both the directions
- **Statistics Chart Display**: Here will show the result of Trip Zone.

A.5 Object Counting


The Object Counting makes store owners easier to calculate the number of people in and out of the store. You may choose one way or two way directions for counting. The numbers can be displayed on screen and saved to the database. It is also useful to calculate the amount of traffic flow on the highway.

- Select **Sensitivity** to set the detection sensitivity level. Higher sensitivity will make it easier to detect and less objects missing, but more misjudgments.
- Select **People / Vehicles / Anything** as the detected objects.
- Select **Calibration (People or Vehicle Object Sizes)**. The minimum and maximum boundary of objects can be specified to improve the detection accuracy. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Min.Size** of Calibration: The width and length values must be 6 pixels at least. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Max.Size** of Calibration: It has to be larger than the minimum size and half the frame size is the most.
- In **Event Conditions**, you can specify the minimum time interval and quantity for each alarm. And go add or edit the IVS event in the **Set Event Action**.
- Enable / Disable the **Counting Result Overlay**.
- Enable / Disable the **Detect Line Overlay**.

- **Reset Counter:** Select the minimum time interval to reset the counter result.
- Select **Rotate Mode** or **Transform Mode** in **Edit Mode:**
 - **Rotate Mode:** User can rotate the zone at will.
 - **Transform Mode:** User can drag the point of the zone to any shape
- **Directionality:** User can select the detected moving direction from one to another or both the directions.
- **Statistics Record:** You can configure your camera in different ways to generate the statistics you required and statistic data can be exported in csv format file.
 - Select **Auto**, camera can send yesterday report to Samba server or FTP server automatically.
 - Select and choose the **Statistics Period** that you want and also you can export or reset the result.
 - **Statistics Chart Display:** Here will show the result of Trip Zone.

A.6 e-Fence

The e-Fence is an electronic fence protection system which is able to detect and send output alert if any object is entering or leaving the boundaries you set in the camera. This function can be used in many applications, either as a standalone protection system or other protection systems such as airports, power plants, radio towers or even military camps.




- Select **Sensitivity** to set the detection sensitivity level. Higher sensitivity will make it easier to detect and less objects missing, but more misjudgments.

- Select **People / Vehicles / Anything** as the detected objects.
- Select **Calibration (People or Vehicle Object Sizes)**. The minimum and maximum boundary of objects can be specified to improve the detection accuracy. The width and length values must be at least 6 pixels. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Min. Size** of Calibration: The width and length values must be 6 pixels at least. If any false detection caused by smaller objects, you can try to increase the minimum size.
 - **Max. Size** of Calibration: It has to be larger than the minimum size and half the frame size is the most.
- **Set Event Action:** Go to the Event Schedule to Add or Edit the IVS event.
- Up to 4 zones can be specified when click the **Add Zone** function. Left click to add the point and 15 points at most can be used in each zone.
- Select **Delete Zone/All** to delete the zones.
- Select **Enable/Disable** to allow the trigger or not.
- **Statistics Chart Display:** Here will show the detection result of e-Fence.

B. How to create App for Dropbox

1 Enable Dropbox then click 'Create App' button



The screenshot shows a configuration window with several server settings sections:

- Mail Server:** Includes an 'Enable' checkbox and a dropdown menu set to 'SMTP'.
- Samba Server:** Includes an 'Enable' checkbox.
- TCP Server:** Includes an 'Enable' checkbox.
- HTTP Server:** Includes an 'Enable' checkbox.
- Google Drive:** Includes an 'Enable' checkbox.
- Dropbox:** This section is expanded. It includes:
 - An 'Enable' checkbox that is checked.
 - Input fields for 'App Key', 'App Secret', 'Authorization String', and 'Access Token'.
 - A 'Create App' button, which is circled in red in the image.
 - 'Get AuthString' and 'Get Infomation' buttons.

At the bottom of the window are 'Apply' and 'Cancel' buttons.

2 Pop up Dropbox- Sign in page, Input Google ID and password then click “**Sign in**” button.



Sign in

or [create an account](#)

☒ Remember me

Sign in

[Forgot your password?](#)

3 Click ‘**Create app**’ button in your apps page.



[Developer home](#)

App Console

[Browse datastores](#)

[Drop-ins](#)

[Core API](#)

[Dropbox for Business API](#)

[Datastore API](#)

[Sync API](#)

[Webhooks](#)

[Developer guide](#)

[Branding guide](#)

[Blog](#)

[Support](#)

Your apps


The Dropbox Platform gives you effortless access to hundreds of millions of Dropboxes. Whether you're building a server-based app with the Core API, syncing structured data with the Datastore API, or just grabbing files with the Chooser, you'll need to create an app to integrate with Dropbox.

You haven't created any apps.


 [Huang Monica](#) ▾

Create app

4 Select 'Dropbox API app' item in Create a new Dropbox Platform app page




- Developer home
- App Console
- Drop-ins
- Core API
- Dropbox for Business API
- Datastore API
- Sync API
- Webhooks
- Developer guide
- Branding guide
- Blog
- Support


 Huang Monica ▾

Create a new Dropbox Platform app

What type of app do you want to create?



Drop-ins app
 Chooser or Saver



Dropbox API app
 Sync API, Datastore API, or Core API

To create a Dropbox for Business app, visit [the Dropbox for Business app creation page](#).

What type of data does your app need to store on Dropbox?

☒ Files and datastores


☐ Datastores only

5 Choose “**Files and datastores**” for ‘What type of data does your app need to store on Dropbox?’

Choose “**No**” for “Can your app be limited to its own folder?”

Choose “**All file types**” for “What type of files does your app need access to?”


What type of data does your app need to store on Dropbox?



☒ Files and datastores

☐ Datastores only


Can your app be limited to its own folder?



☐ Yes — My app only needs access to files it creates.

☒ No — My app needs access to files already on Dropbox.

What type of files does your app need access to?



☐ Specific file types — My app only needs access to certain file types, like text or photos.

☒ All file types — My app needs access to a user's full Dropbox. Only supported via the [Core API](#).

6 Input the app name then click “**Create app**” button.


Provide an app name, and you're on your way.



Monica01

Create app

7 Copy “**App key**” and “**APP secret**” from App page.



App created.

Huang Monica

Developer home
App Console
Drop-ins
Core API
Dropbox for Business API
Datastore API
Sync API
Webhooks
Developer guide
Branding guide
Blog
Support

Monica01

Settings Details App metrics Error logs

Status Development [Apply for production](#)

Development users Only you [Enable additional users](#)


Permission type Full Dropbox [?](#)

App key tqzw4vixp7aee5w
App secret r8got55yqb9rykl

OAuth 2 Redirect URIs [Add](#)

Allow implicit grant [?](#)

8 Paste the “**App key**” and “**APP secret**” to BU-3028 Dropbox settings then click ‘**Get AuthString**’ button.



Dropbox

☒ Enable

App Key : tqzw4vixp7aee5w [Create App](#)

App Secret : r8got55yqb9rykl [Get AuthString](#) [Get Information](#)

Authorization String :


Access Token :

[Apply](#) [Cancel](#)

9 Click “Allow” button




Monica Huang




10 Copy the key



Monica Huang



11 Paste the key to **BU-3028 Authorization String** then click ‘Apply’ button



12 It will create “**Access Token**” key automatically.

Dropbox

☒ Enable

App Key :

App Secret :

Authorization String :

Access Token :

13 Click “**Get Information**” button will pop up “**Account , Country, Email**” information.

Google Drive

☒ Enable

User Name :

Password :

Dropbox

☒ Enable

App Key :

App Secret :

Authorization String :

Access Token :

Message from webpage

Display Name :Huang Monica
Country :TW
Email :kugan.monica@gmail.com