VoIP-440S Setup example

1. Power on the VoIP-440S
2. Use the computer to connect the config port to setting VoIP-440S

The computer setting DHCP mode then will got the DHCP IP form VoIP-440S.

3. The default password is **root**



4. Setting the SIP account info

OvisLink
The Total Networking Solutions

Home
WAN
SIP
CODECS
System
Download
Logout
Reset

SIP | SIP Extensions | OOB Signalling | ToS/DiffServ | VLAN

SIP Server Settings (Current Server: sip.voipbuster.com : 5060 ; Domain: sip.voipbuster.com; VoicePort: 5060)

* Server Address: sip.voipbuster.c (IP or FQDN)
* Port: 5060
Domain Name: sip.voipbuster.com
Voice Port: 5060
☑ Send Registration Request with Expire Time 300
Outbound Proxy IP: (IP or FQDN)
Outbound Proxy Port:
Stun Server IP: stun.voipbuster. (IP or FQDN)
Stun Server Port: 3478

Gateway Settings

Dial Plan:
☐ # use as a quick dial function
☐ To enable # to be recognized as dial number
☐ To enable * to be recognized as dial number

	Phone Number	CallerID Name	Port	AEC On	User Name	Password	Dial-in Pla
Line1:	201	201	5060	OFF	markairlive	••••••••••	
Line2:	202		5061	ON			
Line3:			5062	ON			
Line4:			5063	ON			

* Leaving a setting blank will force the unit to use the information obtained via DHCP and/or DNS

Save SIP Settings

5. Setting the codec info



6. After save and reboot, then start to make VoIP calls.