The Printer Server and Printer' s setting step on Linux (Redhat 7.3)

Composed By: Jacky_Yeh
E-mail: jacky_yeh@mail.cellvision1.com.tw

This document and the information contained herein are the property of Cellvision Corporation and reproduction by any Cellvision' s means (be limited to Xerox graphic by chemical and electronic.) and distribution is expressly prohibited without prior written consent from Cellvision. Moreover, the document and information contained herein are confidential and may not be divulged without expressly written consent from Cellvision.

1. Key in ‘setup’ in X-Window.

2. It appears Text Mode Setup.

3. Select Printer configuration item and key Tab to select the Run tool button, and then key enter to go to the next step.

4. Key Tab to select the New button, and key enter to go to the next step.

5. Key in the printer name (ex. HPLJ5MP) in the Queue Name table and key Tab to select Jetdirect Printer, then key Tab to select the Next button, and then key enter to go to the next step.

6. Key in the printer server' s IP address (ex. 172.16.135.209) in the Ip table and key Tab to key in the port number (ex. P1: 9100, P2: 9101, P3: 9102) in the Port table and key Tab to select the Next button, and then key enter to go to the next step.

7. Select the printer' s driver and key Tab to select the Next button, and then key enter to go to the next step.

8. See the data of the printer setting. If it is all right, key enter to go to the next step.

9. Key Tab to select the Test button and key enter to test the printer' s setting is O.K.

10. Key enter to test.

11. Select the test item (ex. US Letter PostScript Testpage) and key Tab to select the Test button, and then key enter to print and go to the next step.

Wait to print…

12. If the test item is all right, key enter to go to the next step.

13. Key Tab to select the Exit button and key enter to exit.

14. Key Tab to select the Quit button and key enter to exit the Text Mode setup.

15. Complete.