AirLive®
Powered by OvisLink Corp.
www.airlive.com

QIG for the live view of embedded NVR

by Smart Phone Blackberry & iPhone

//For the installation on iPhone, please directly jump to the end of the pages.

● **Support Blackberry models:**

| Model	9530	8900	9000	8220
FW version	V.4.7.0.75	V.4.6.1.199	V4.6.0.190	V4.6.0.195

● **Mobile Configuration**

1. Select Options from MENU

2. Choose " Browser configuration"

3. Enable "Support JavaScript"

4. Save configuration

5. Enter IP address of NVR series and see Live View of your NVR

6. Select the channel from the drop down bar

7. Select the Image Size of the network camera

Note: Image Size is based on the video resolution of your network cameras.

8. PTZ control function

Note: This function is only applicable for the PTZ cameras.

● **Live Monitoring**

Please go to "Safari", enter the "IP address" of the installed NVR, complete ID,
Password then you can log in and see the live images simultaneously.