

HotSpot

When hotspot authentication is enabled, PCs will get a Pop-Up window when they try to access the Internet.

They must enter correct username and password to access Internet. If PC connect to the LAN, it will not goes to the authentication page.

If PC try to connect to the internet, it will goes to the authentication page.

IE Browser

- As PC shows the page, please click continue to this website, and it will goes to the authentication page.



There is a problem with this website's security certificate.

The security certificate presented by this website was not issued by a trusted certificate authority.
The security certificate presented by this website has expired or is not yet valid.
The security certificate presented by this website was issued for a different website's address.

Security certificate problems may indicate an attempt to fool you or intercept any data you send to the server.

We recommend that you close this webpage and do not continue to this website.

Click here to close this webpage.

Continue to this website (not recommended).

More information

- Input the User Name and Password that you add and than PC is able to access internet.



Air Live **Air 3G** www.airlive.com
Wireless-N 3G PoE Router

Please enter the account information to access the Internet.

User Name:

Password:

Login

- When PC show the Successful message, it is able to surf web page.



Firefox

- As PC shows the page, please click Add Exception, and it will goes to Add Security Exception page.



- Please Click Comfirm Security Exception, and it will goes to the authentication page.



- Input the User Name and Password that you add and then PC is able to access internet.



- When PC show the Successful message, it is able to surf web page.

