


Question:

For some reason, my PC will restart itself automatically. But it is not good to my surveillance software. I have to restart and log in the program manually and it is not that easy for me if this happened in the midnight. How can I solve this situation?

Answer:

In this situation, please use the Auto Start and Auto Login function in our CamPro HD. You can refer to the steps below for configuring these functions.

1. Go to **“System Setup → User”** for setting the user’s password for the account you would like to use for auto login.



2. Go to **“System Setup → System”**, check the Auto Start and Auto Login function. Then assign the account you would like to use for auto login.

