




You can connect console port of SNMP-FSH2602MG v2 to PC via RS-232 cable. When the connection between Switch and PC is ready, turn on the PC and run a terminal emulation program or **Hyper Terminal** and configure its **communication parameters** to match the following default characteristics of the console port:



After finished the parameter settings, click “**OK**”. When the blank screen shows up, press “**Enter**” key to bring out the login prompt. Key in the “airlive”(default value) for the both User name and Password (use **Enter** key to switch), then press Enter key and the Main Menu of console management appears

Go to the “**Switch Configuration/Administration Configuration/IP Configuration**” to check the IP address of SNMP-FSH2602MG v2.

