

How to solve laptop display function key fail after use AirVideo-2000.

Please try to check the Hardware acceleration setting.

If setting is not like below, please follow the sequence settings of the picture then try to change display mode again.

