



# FAQ\_How to make phone call from/to iPhone via VoIP?

We use the iPhone and VoIP-120A to perform this test as following topology.



**Step1:** Fill the SIP account and password into the VoIP-120A and please make sure the SIP account has register success or not.



## Service Domain Settings

You could set information of service domains in this page.

Realm No.:

Realm	
Active:	<input checked="" type="radio"/> On <input type="radio"/> Off
Display Name:	<input type="text" value="30004502"/>
User Name:	<input type="text" value="30004502"/>
Register Name:	<input type="text" value="30004502"/>
Register Password:	<input type="password" value="....."/>
Domain Server:	<input type="text" value="211.20.66.50"/>
Proxy Server:	<input type="text" value="211.20.66.50"/>
Outbound Proxy:	<input type="text"/>
Subscribe for MWI:	<input type="radio"/> On <input checked="" type="radio"/> Off
Status:	Registered
<input type="button" value="Submit"/> <input type="button" value="Reset"/>	


**Step2:** Install the SIP client application into iPhone. After installed completely, the icon will show on the desktop of iPhone.



**Step3:** Select **SIP** option.



**Step4:** Choose the SIP provider and here we use the AirLive SIP server.



**Step5:** Fill the SIP account and password.



**Step6:** Check the SIP has register success or not.



**Step7:** Call in & Call out by the SIP number.

