



WH-9200AP Dual Band

Connection Guide

For AP vs. Client Mode





Copyright & Disclaimer

The information in this guide is for your reference only. OvisLink Corp. does not guarantee the accuracy of its content, please use with caution. The content is subject to change without notice. All trademarks are property of their respective owners.




© 2009 OvisLink Corporation, All Rights Reserved

Table of Contents

Overview.....	1
Devices:.....	1
Configuration.....	2
1. Topology:	2
2. WH-9200AP Settings.....	3
3. WH-5420CPE Settings	8
4. AirMax5 Settings	10

Overview

This document guides we use WH-9200AP to connect two wireless networks simultaneously that radio1 is 802.11b/g mode and radio2 is 802.11a mode in 2km.



Devices:


1. WH-9200AP (firmware version is v1.00e07a)
2. WH-5420CPE (firmware version is 5420cpe_e1_eu)
3. AirMax5 (firmware version is 1.00e13)
4. PC *

Configuration

1. Topology:

In this sample, we are going to introduce you to connect WH-5420CPE and AirMax5 with the “dual AP mode” of WH-9200AP. The radio1 of WH-9200AP is 802.11a band that connects to AirMax5 via WPA2-PSK encryption, and the radio2 is using 802.11b/g band to connect with WH-5420CPE via WPA-PSK encryption.


Before the process, please change the IP address of each PC and direct the devices with the following topology.




2. WH-9200AP Settings

Step 1. Login the device and enter the Dual AP Mode.

1. In PC1, type “WH-9200AP’s IP address” into the web browser’s address field to access the device.① (default IP is 192.168.1.1)
2. Press the “Wireless Settings” button② then key-in the password to login the device.③ (default password is “airlive”)



3. Press the “Setup” button of Dual AP mode to into the set up page.⑤



The screenshot shows the 'Operation Mode' configuration page for the WH-9200AP. The 'Dual AP' mode is selected. A red circle with the number 5 highlights the 'Setup' button next to the 'Dual AP' mode selection.

Mode	Setup	Radio 1	Radio 2
<input checked="" type="radio"/> Dual AP	Setup 5	AP Mode	AP Mode
<input type="radio"/> Duplex Mode	Setup	WDS Bridge	WDS Bridge
<input type="radio"/> Dual Bridge	Setup	Bridge	Bridge
<input type="radio"/> Separate Bridge	Setup	Bridge	Bridge
<input type="radio"/> AP + Client	Setup	AP Mode	Client Mode
<input type="radio"/> Client + AP	Setup	Client Mode	AP Mode
<input type="radio"/> AP + Bridge	Setup	AP Mode	Bridge
<input type="radio"/> Bridge + AP	Setup	Bridge	AP Mode
<input type="radio"/> Bridge + Gateway	Setup	Bridge	Gateway Mode
<input type="radio"/> Gateway + Bridge	Setup	Gateway Mode	Bridge
<input type="radio"/> AP + Gateway	Setup	AP Mode	Gateway Mode

Step 2. Encryption and connection settings for Radio 1.

1. Check the Radio1 and Radio2 is already enabled.
In this sample, the SSID, Radio Mode and the channel number are using default settings to show as following picture.
2. Please press the “Setup” button of security settings to show the “Security Settings” dialog box.①


www.airlive.com

WH-9200AP Dual Radio Dual Band Outdoor AP

| Operation Mode | System Configuration | Device Status | Logout |

© Operation Mode
© Dual AP

Dual AP



Regulatory Domain: United Kingdom

WLAN Standard for Radio 1

Enable Radio 1
Network ID(SSID) AirLive1

Disable SSID Broadcasting
Mode: 11a
Channel: 36
Security: (1)

WLAN Standard for Radio 2

Enable Radio 2
Network ID(SSID) AirLive2

Disable SSID Broadcasting
Mode: 11a
Channel: 36
Security: (1)


3. In our sample, we use these parameters:

Security: WPA2-PSK (2)

Key string: 12345678 (3)


Type: Both (TKIP/AES Mix)

Remember press “Apply” button to save the settings. (4)




(If you want to use other encryptions, you must use the same as AirMax5's wireless encryptions.)

4. Press the “Setup” button of Advanced Settings to show the “Advanced Wireless Settings” dialog box⑤, then press “ACK Calculator” button⑥. It shows “802.11a/SuperA ACK Calculator” dialog box. Please enter the distance between WH-9200AP and AirMax5⑦, then press the “Tab” button on your keyboard, at this time it shows the Ack time out value in the field.
 (In this sample, the distance is 2000m; the Ack Time Out is 37)
 You can copy the value to paste with “AckTimeOut(11a/SuperA)” field⑧.
 Remember press “Apply” button to save the settings⑨.




Step 3. Encryption and connection settings for Radio 2.

1. Check if the Radio2 is 11b/g mode and the channel number is 11.
 In this sample, the SSID is “AirLive2” by default.
 2. Please press the “Setup” button of security settings to show the “Security Settings” dialog box.①
 3. In our sample, we use these parameters:
 Security: WPA-PSK②
 Key string: 12345678③
 Type: Both (TKIP/AES Mix)
- Remember press “Apply” button to save the settings.④



(If you want to use the other encryptions by yourself, you must use the same as WH-5420CPE's encryptions.)


- Press the “Setup” button of Advanced Settings to show the “Advanced Wireless Settings” dialog box⑤, then enter the Ack Time Out value in “AckTimeOut(11g/SuperG)” field⑥. The value is the same as 11a. (In this sample, the Ack Time Out is 37)
- Remember press “Apply” button to save the settings.⑦⑧



3. WH-5420CPE Settings


Step 1. Login the device and change to the Client Mode.

1. In PC3, type “WH-5420CPE’s IP address” into the web browser’s address field to access the device. (default IP is 192.168.100.252)
2. Press the “Mode” button① then select “Client”② to change operation mode.




Step 2. Site survey and connect with WH-9200AP.

1. In the Client Mode Settings page, please press “Site Survey” button to survey the signal in your environment①.



2. You can see the SSID with WH-9200AP's Radio2, then select it②→ Press "Connect" button③. (In our sample the SSID is "AirLive2")



SSID	BSSID	Channel	Type	Encrypt	Signal	Select
AirLive2	00:4f:69:6e:25:61	11 (B+G)	AP	WPA-PSK	69	<input checked="" type="radio"/>
AAAirlive	00:4f:62:94:02:11	6 (B+G)	AP	WPA-PSK	33	<input type="radio"/>


3. And then, set the encryption that should be the same as WH-9200AP's Radio 2.

In our sample, we use these parameters:

Security: WPA-PSK(TKIP)④

Key string: 12345678⑤

Then press "Apply Changes" button that will connect to WH-9200AP's Radio2 automatic.



Step 3. Check the connection.

After configured successfully, you can ping the PC1's IP from PC3 to check if the connection was successful.

```
E:\Documents and Settings\Administrator>ping 192.168.1.101  
Pinging 192.168.1.101 with 32 bytes of data:  
  
Reply from 192.168.1.101: bytes=32 time=1ms TTL=128  
Reply from 192.168.1.101: bytes=32 time=1ms TTL=128  
Reply from 192.168.1.101: bytes=32 time=2ms TTL=128  
Reply from 192.168.1.101: bytes=32 time=3ms TTL=128  
  
Ping statistics for 192.168.1.101:  
    Packets: Sent = 4, Received = 4, Lost = 0 <0% loss>,  
    Approximate round trip times in milli-seconds:  
        Minimum = 1ms, Maximum = 3ms, Average = 1ms
```



If you can't ping the PC1, please check the firewall is already disable of PC1's OS.

4. AirMax5 Settings


Step 1. Login the device and change its IP.

1. In the PC2, type the AirMax5's IP address into the web browser's address field to access the device.① (default IP is 192.168.1.1)
2. Key-in the password to login the device.② (default User name and password are "airlive")
3. If your AirMax5's IP is the same as WH-9200AP's IP, you have to change another IP address to avoid the conflict. The same IP addresses can't exist in one LAN.


In this case, please press the "System configuration" button to go to the "Device IP Settings" page.④




4. In our sample, we change the device's IP to 192.168.1.2^⑤ → press "Apply"^⑥ → "OK".^⑦



5. Access the device as new IP^⑧ then press the "Wireless Settings" button^⑨.



6. Press the “Setup” button of Client Infrastructure mode to into the set up page.^⑩



Mode	Radio	Ethernet Port
<input type="radio"/> Access Point	Setup	Access Point
<input type="radio"/> Repeater	Setup	Repeater
<input type="radio"/> WDS Bridge (Pure MAC)	Setup	WDS Bridge
<input type="radio"/> Bridge Infrastructure	Setup	WDS Station
<input checked="" type="radio"/> Client Infrastructure	Multi-User <input type="button" value="▼"/>	Setup
<input type="radio"/> Client Ad-hoc	Setup	Wireless Client
<input type="radio"/> WISP Router	Setup	Point to Point
<input type="radio"/> AP Router	Setup	Client Router
	Setup	Access Point
	Setup	WAN

Step 2. Connect to 9200AP via WPA2-PSK encryption.


1. Check if the “Radio Mode” and “Channel Width” were the same as WH-9200AP.
2. Enter the distance between WH-9200AP and AirMax5 in “Distance” field^① then press “Apply” button to save the distance setting.^②
After configured successfully, please press “Site Survey” button to site survey the signal in your environment.^③

④ Wireless Settings

Regulatory Domain:	United States	<input type="button" value="▼"/>
Network ID (SSID)	airlive	<input type="button" value="Site Survey"/> ③
Lock to AP:	<input type="button" value="Setup"/>	
<input type="checkbox"/> Cloned MAC Address	00-00-00-00-00-00	(xx-xx-xx-xx-xx-xx)
Radio Mode:	11a	<input type="button" value="▼"/>
SuperA Option:	<input checked="" type="checkbox"/> Bursting <input checked="" type="checkbox"/> Compression <input checked="" type="checkbox"/> Fast Frames	
Channel:	AUTO <input type="button" value="▼"/>	
Channel Width:	Normal (20MHz) <input type="button" value="▼"/>	
Security Setting:	<input type="button" value="Setup"/>	
Distance:	① <input type="text" value="20000"/> meters	
Antenna Setting:	Vertical <input type="button" value="▼"/>	
Transmit Power:	24dBm <input type="button" value="▼"/> (Approximate TX Output Power)	
DFS Control:	Enable <input type="button" value="▼"/>	
Advanced Settings:	<input type="button" value="Setup"/>	
Bandwidth Control:	<input type="button" value="Setup"/>	
RSSI LED Thresholds:	<input type="button" value="Setup"/>	

② 

3. Then it will **show** the site survey result of the “Site Survey” dialog window. You can see the SSID with WH-9200AP’s Radio1, then select it④ → Press “ASSOCIATE” button⑤. (In our sample the SSID is “AirLive1”)



Site Survey

Site survey list:

Select	ESSID	MAC Address	Conn Mode	Channel	Turbo	Super	XR	WME	Signal Strength (dbm)	Security	Network
<input type="checkbox"/> ④	AirLive1	00-4f-69-6e-25-60	A	36	-	-	-	*	-67	WPA2 PSK	AP

NOTE: The sitesurvey will show both AP and Bridge connections. Device without ESSID is more likely to be a Bridge device.

⑤

4. Then it shows the “Security Settings” dialog box.


In our sample, we use these parameters:

Security: WPA2-PSK^⑥

Key string: 12345678^⑦

Type: Both (TKIP/AES Mix)

Remember press “Apply” button to save the settings.^⑧



(If you want to use other encryptions, you must use the same as WH-9200AP Radio 1's encryptions.)

Then it will connect to WH-9200AP's Radio1 automatic.

Step 3. Check the connection.

After configured successfully, you can ping PC3 from PC2 to check if the connection was successful.

```
Microsoft Windows XP [版本 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

E:\Documents and Settings\Administrator>ping 192.168.1.103
Pinging 192.168.1.103 with 32 bytes of data:
Reply from 192.168.1.103: bytes=32 time=13ms TTL=128
Reply from 192.168.1.103: bytes=32 time=3ms TTL=128
Reply from 192.168.1.103: bytes=32 time=3ms TTL=128
Reply from 192.168.1.103: bytes=32 time=2ms TTL=128

Ping statistics for 192.168.1.103:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
    Minimum = 2ms, Maximum = 13ms, Average = 5ms
```

If you can't ping the PC3, please check the firewall is already disable of PC3's OS.