

Q. Why can I not change my IP address from DHCP to Static?

LAN Interface

DHCP IPv4 DHCP IPv4/IPv6 Static IPv4/IPv6

IP Address(IPv4) : 192.168.1.196

IP Address(IPv6) :

Prefix Length :

Subnet Mask : 255.255.255.0

Gateway : 0.0.0.0

Primary DNS : 192.168.0.254

Secondary DNS : 0.0.0.0

HTTP Port : 80

RTSP Port : 554

RTP Data Port : 5556

When this happens it means you have both a working WIFI and LAN connection. To change your LAN static IP address

Please first go to "Network" → "Wireless" and disable the Wireless (remove the checkmark) and press APPLY.

Wireless

Enable

Survey :	ESSID	MAC	Channel	Mode	Signal	Encryption	Refresh
	bluesky	02:1f:1f:00:00:02	2	Infrastructure	100%	WPA2PSK/AES	Choose
		c8:6c:87:28:18:bb	3	Infrastructure	47%	WPAPSK/TKIP	Choose
	TWM	56:d9:98:bb:d2:c3	6	Infrastructure	37%	NONE	Choose
	TIMOTION-WIFI	2a:a4:3c:a3:d0:71	6	Infrastructure	37%	WPA1PSKWPA2PSK/TKIPAES	Choose
	LO	0c:47:2d:fa:2b:28	6	Infrastructure	52%	WPA1PSKWPA2PSK/AES	Choose

MAC : 7C:DD:90:8F:45:43

SSID : AirLive9F

BSSID :

Interface: Wired(Ethernet) Only Both LAN and Wireless

Security Mode: WPA/WPA2

Key: ●●●●●●

After the settings are applied go back to “Network” → “General” and you will be able to check mark Static and enter your IP address.

LAN Interface

DHCP IPv4 DHCP IPv4/IPv6 Static IPv4/IPv6

IP Address(IPv4) : ×

IP Address(IPv6) :

Prefix Length :

Subnet Mask :

Gateway :

Primary DNS :

Secondary DNS :

HTTP Port :

RTSP Port :

RTP Data Port :

When you would also like to use WIFI you can now go back to to “Network” → “Wireless” and enable the Wireless (checkmark) and press APPLY.