

Q: What do the green LEDs on the side of the Gateway mean?

- a. Plug RJ45 cable to LAN port
- b. Please connect the 12V 1A adapter to the gateway's DC JACK.
- c. When the network is built, Ethernet LED light will flash.
- d. (Power & WiFi LEDs should be ON)

