


Q: I want connect Air3GII to another AP by WDS function. How do I know the WLAN MAC address of Air3GII?

A:

1. Please connect your PC to Air3GII and get into the web management of Air3GII.(Default IP :192.168.1.254)
2. Please add the “**sysinfo.htm**” after the IP address as below picture:



3. Then you will see the WLAN MAC address.

R-Data	WLAN MAC=00-4F-67-03-F0-62/OVS6E3201001 LAN MAC=00-4F-67-03-F0-61 WAN MAC=00-4F-67-03-F0-60 PV=1 F/W version= F/W Checksum=
--------	--