

Q. How to use the CamPro Professional Calculator?

A. Please see the explanation below:

Please enter those properties of your IP cameras.

Total Channel Count	36	CPU Speed (GHz)	30
Frame Rate (FPS)	30	CPU Core	4
Resolution (Width)	320	Display (Codec)	H.264
Resolution (Height)	240		

Functions	Enabled Channels
System	N/A
Motion Detection	
Camera Tamper	
Object Loss (ROI * 1)	
Tripwire	
Foreign	
Object Counting	
Face Counting	
Total	N/A

CPU Loading (%)	Display FPS
83.15	30.00
0.00	
0.00	
0.00	
0.00	
0.00	
0.00	
0.00	
83.15	

If you have enabled any of IVS function, please also enter them here.

And the result will be shown here.