

### How to adjust MD-3025/ MD-3025-IVS focus?

### 1. Unscrew two screws



### 2. Pull the cable gently



### 3. Remove the top cover







# 4. Pull the robber ring gently.







### 5. Adjust the focus



## The desiccant replacement

Please replace the desiccant to avoid the moisture in the MD-3025.

1. There are two new desiccants in the box.



#### 2. Unscrew two screws





3. Replace two desiccants.

