



How to open the plastic cover


No need to unscrew the screws.

1. Find the plastic point



2. In the opposite site, open the cover by nail.





Open Here by nail