


How To View WL-1200CAM via Smart Phone.

If you want to watch the live view from IP camera WL-1200CAM by smart phone, you can type this link into browser

<http://<WL-1200CAM's IP address>/snapshot.cgi>



Or you can download the APP "**Netcam Viewer**" from APP store. (IOS only)
After installing the APP successfully, please follow below steps to set this APP:

Step 1: Edit Camera

Enter camera details

Cancel **Edit Camera** **Done**

Identification

Name wl-1200cam Enter the name you want.

Folder Root >

Give an item a clear name to quickly identify it. Group related items into folders.

Connection Enter the right IP address and port number.

http:// 192.168.0.77/snapshot.cgi : 80

Discover local cameras >

Use local discovery to quickly add Axis or Mobotix cameras on your local network. You can also manually enter or paste information in the address field

Authentication

Username admin

Password ●●●●●●

For safety, many cameras require a username and password. Enter this information in this section.


Type Section

Camera Type Custom Please chose "Custom" >

Options Setup the "Option" >

The camera type information is required to communicate with a camera. More detailed features can be configured by tapping "Options"

Step 2: Camera Options



Step 3: When the settings are all finished, please click the Camera Icon to view.



Step 4: Congratulations! Now you can view WL-1200CAM via your smart phone!

