


How works the ICR function in Camera?

Ans:

You can choosing the ICR mode in your Camera.



*Night mode: IR always open (grayscale mode).

*Day mode: IR always close.


*Auto mode:

Detect the light of environment automatically.

You can adjust the Left gray button & Right gray button. (red button is "the light current value of environment")

when red button < Left gray button --> IR open (grayscale mode).

when red button > Right gray button --> IR close (Day mode).



*Schedule: IR open or close by schedule.