

Q : How to set up the DDNS function of N.Plug?

A : Please follow the followings to configure the DDNS function:

1. Please register a account from a service provider. (For example: www.dyndns.com)
2. Please change the hardware switch bar to Router .



3. Please login the web management of N.Plug, the default User name is admin, the default password is airlive.



4. Please get into the DDNS page.

www.airlive.com

Air Live ¹ **N.Plug** Wireless-B/G/N Power Adapter AP

Wizard | **Internet Settings** | Wireless | System | Status | Reboot

WAN Settings
Port Filtering
IP Filtering
MAC Filtering
URL Filtering
Port Forwarding
DDNS ²
DMZ
Route Setup

DDNS

Dynamic DNS is a service, that provides you with a valid, unchanging, internet domain name (an URL) to go with that (possibly everchanging) IP-address.

Enable DDNS

Service Provider : DynDNS

Domain Name : airlive.dyndns.org

User Name/Email: airlive

Password/Key:

Note:
For TZO, you can have a 30 days free trial [here](#) or manage your TZO account in [control panel](#) For DynDNS, you can create your DynDNS account [here](#)

Apply Change Reset

5. Please select the Service Provider, and input the Domain Name ,the User Name/Email, the Password/Key which are registered at the service provider.

Example :

- Select the Service Provider as DynDNS.
- Input the Domain Name as airlive.dyndns.tv
- Input the User Name/Email as airlive
- Input the Password/Key

Wizard | **Internet Settings** | Wireless | System | Status | Reboot

WAN Settings
Port Filtering
IP Filtering
MAC Filtering
URL Filtering
Port Forwarding
DDNS
DMZ
Route Setup

DDNS

Dynamic DNS is a service, that provides you with a valid, unchanging, internet domain name (an URL) to go with that (possibly everchanging) IP-address.

Enable DDNS

Service Provider : DynDNS

Domain Name : airlive.dyndns.org

User Name/Email: airlive

Password/Key:

Note:
For TZO, you can have a 30 days free trial [here](#) or manage your TZO account in [control panel](#) For DynDNS, you can create your DynDNS account [here](#)

Apply Change Reset

6. Please click the Apply Change button, and reboot N.Plug to make the change effective.