

How to connect WLA-5000APv3 using WDS Bridge

The topology is like below. When WDS connection is establish, they should meets four requirement.

1. The wireless mode should be the same.
2. The WLA-5000APv3 should added the remote WLA-5000APv3 wireless MAC address.
3. The channel should be the same.
4. The Security should be the same.

After configuration, the WLA-5000APv3 will be connected automatically.

Note:

1. The ssid is not the condition makes WDS connection.
2. Please turn on the 802.1d STP at Advanced Settings >> Wireless Settings to avoid network loop.

