


Where can I find the wireless MAC address for WDS connection of my AP60?

1.>Login web management of AP60



2.>Please select "Status" from top menu bar, and then look at "BSSID" under the Wireless Configuration.

