

Why is the Motion Detection recording is stop on my NVR after one week?

Air Live	NVR8 Network Video Recorder	System Time: August 26, 2013 09:33 User: <u>ac</u>
<u>NVR Setup</u> • System Configuration	General Setting	Help
 Channel Configuration 	Event Trigger Duration	
 Event Configuration <u>General Setting</u> DI Setting Event Servers FTP Servers SMTP Servers Event Trigger Recording Configuration System Options 	Always Only during: Sun Mon Tues Wed Thur Fri Sat Start Time: OV : OV End Time: OV : OV Event Trigger Interval Interval: 5 Seconds. (5~86400) Trigger Actions	
	Subject: <time> : <ch> <trigger> from < Send Message Text: FTP File Name:</trigger></ch></time>	<p></p>

Please check the "Event Trigger Duration" is set to "Always".

