

Q : Why the PTZ function of the camera move slowly?

A :

The speed of the PTZ function can be adjusted easily, just click on the PTZ Control and move the speed bar to the proper position as shown below snapshot.

