

## MD5 Authentication on New Releasing Firmware

The MD5 authentication is for ensure users a complete firmware, AirLive adopt MD5 authentication on new releasing firmware. From now on, please verify the MD5 checksum of downloaded firmware with a MD5 sum checker to check for its completeness.


Do not upgrade the IAR-5000 with firmware of which the MD checksum diverging from the one we provided. Please contact us if the problem has not been solved by downloading the firmware again or re- verify the MD5 checksum.

MD5Summer is available at <http://www.md5summer.org/>

### ※ How to use MD5Summer?


**Step 1:** Run MD5Summer by double-clicking on it.

**Step 2:** Select the folder where the firmware is saved and click on **Create sums**.



**Step 3:** Click **OK** after adding the firmware to be summed.

## MD5 Authentication on New Releasing Firmware



**Step 4:** Verify the MD5 checksum with the one we provided.

