




SmartCube 300W

**Intelligent 3MP Wireless Cube IPCAM
with Temperature and Humidity Sensor**


WiFi Setup

WiFi Setup using Smartphone/Computer and router with WPS push button

Please check if your wireless router has "**WPS Push Button**" shown as an example in the picture below. If it does, please use this guide.




I/O Interface




Plug the adapter

Plug the power cable into the camera.




Power on SmartCube 300W

When SmartCube 300W is powered on, the green led will be on first. After SmartCube 300W is ready, the red led will be on and the green led will be off.




WPS Wireless connection

To make the wireless connection, click WPS button on the router first.



WPS Wireless connection

Click WPS/Reset button on the Smartcube 300W within 2 minutes after press the WPS on the router. When SmartCube 300W connects to the router successfully, the green led will be flashing.



WiFi Connection Notice

WPS connection.(WPS function only supports that the router is in WPA2 AES security protocols or no protected password.)



Download the AirLive APPCAM APP

After you connect to internet, please visit App Store or Google Play to download AirLive APPCAM APP. You can use QR code scanner software directly or simply search the “AirLive APPCAM”.



App Store



Google Play



Appendix Support

You can download the complete guides and supporting programs from <http://www.airlive.com/product/smartcube-300w/download>, or scan the QR code here.



Please consult with the FAQs <http://www.airlive.com/product/smartcube-300w/faq> before writing to OvisLink Tech Support Team for further assistance



For any other question, please read the user manual in the CD or mail to tech@airlive.com for technical support.