While DHCP Server was enabled , then if you want to make a fixed mapping between the MAC address and the assigned IP address . You may refer to below steps.

1.> Press "DHCP Server" , then press the "Fixed Mapping"

2.> Enable the "MAC Address Control" and select the DHCP clients from the pull list.

3.>Select the "Fixed Mapping ID" and press "Copy to" button , then DHCP client's IP and MAC address will be copied to the Fixed Mapping Table.

4.> Then DHCP Server will reserve the special IP for designated MAC address.