Improving Night Mode Video Quality for BU-720 and DM-720

1. Procedures

1. Go to the camera's web configuration page.

2. Click on "Configuration"->"Camera Settings"->"Image" menu.

3. Change the Exposure Time(Max) to "1/60" as shown in the diagram above.

4. Click "Save" on the bottom of the page to save settings.

5. Click on "Low Light behavior Setting" button.   A new window will pop up.

6. Change the Mode to "Night Mode"

7. Change the Exposure Time(Min) to "1/120"

8. Change the Exposure Time(Max) to "1/30"

9. Change the Gain(Max) to "8"

10. Click on "Save" to save settings.