SD-2020-ST Smart Key Installation.

1. Click Smart Tracking at Smart Tracking and Insert Key



2. Key in SD-2020 Product Key to enable Smart Tracking then it will show Authentication is successful message.




Air Live
Home
System
Streaming
PTZ
Logout
SD-2020
www.airlive.com
System
Security
Network
DDNS
Mail
FTP
HTTP
Application
Motion detection
Network failure detection
Smart Tracking
Smart Tracking
Insert Key
Storage management
Recording
Smart Tracking
Smart Tracking
Off
On
MAX Limit Setting
Enable tilt limit
Turn Off
Enable pan limit
Detection Range
L(60%)
M(50%)
S(40%)
Home Setting
Guard Timer Setting
save
x1
Zoom
Wide
Tele
Focus
Auto
Manual
Near
Far


Air Live
Home
System
Streaming
PTZ
Logout
SD-2020
www.airlive.com
System
Security
Network
DDNS
Mail
FTP
HTTP
Application
Motion detection
Network failure detection
Smart Tracking
Smart Tracking
Insert Key
Storage management
Recording
Schedule
File location
Smart Tracking
Smart Tracking
Off
On
MAX Limit Setting
Enable tilt limit
Turn Off
Enable pan limit
Detection Range
L(60%)
M(50%)
S(40%)
Home Setting
Off
On
Set
Go
Time: 0 [sec.]
Guard Timer Setting
Off
On
Time: 0 [sec.]
save
x1
Zoom
Wide
Tele
Focus
Auto
Manual
Near
Far