Air Live

Smart Life

IOT For Home

Smart Home Kit QIG for APP

APP Operation Guide

Air Live
Smart Life IOT For Home

AirLive Smart Life APP Operation Guide

About the Smart Life APP

AirLive Smart Life APP features "**Smart Rules**" to make your life easier.

Sensors: Turn on/off individual devices

Room: Create different settings for rooms

Scene: Make multiple actions such as turning on multiple lightings at the same time.

Macro: Set "**IF->Then**" conditions. For example, if the interior illumination is below certain level, the light will turn on.

Schedule: Create activities at different time of the day. For example, turn on the stereo to play your favorite music when waking up.

01 Execute the Smart Life APP

Click the "**AirLive Smart Life**" icon on your smart phone

02 APP Setting

Click "**downward arrow**" icon to edit the Gateway name, delete the Gateway, or change default password

Gateway 1
9YCDGDNP1JZRVH9SMU51

+ Gateway

Gateway 1
9YCDGDNP1JZRVH9SMU51

+ Gateway

Edit

Delete

Change Password

Cancel

APP Operation Guide
APP introduce

03 Enter the APP Main Screen

Click the "**Gateway name**" to enter the main screen.

Gateway 1
9YCDGDNP1JZRVH9SMU51

+ Gateway

04 Intruder Alarm

Click the padlock to close, then security will be in armed mode.

**Note: If door/window or Motion is triggered, user will receive a notification.**

Home Security Alarm

Sensors   Rooms   Scenes   Macros   Schedules

APP Operation Guide
APP introduce / Room Setting

05 Sensor Screen

All included sensors will be shown on the Sensors Tab.


Air Live
Smart Life IOT For Home

Room

Room Setting

01 Add New Room -1

Click icon --> Settings and enter the Advance settings page

02 Add New Room -2

Click "**Room**"

# APP Operation Guide
Room Setting

03 Add New Room -3

Click "+" to add new room.

Back   Next

04 Add New Room -4

Provide a name for the room.

Close   Title

Add New Title

Test

OK

完成

"Test"   Testing   Tests

q w e r t y u i o p
a s d f g h j k l
z x c v b n m
123   space   return

05 Add New Room -5

Click "**+**" to add sensors.

Note: Once a sensor has already been placed in a room, it cannot be added to another room.

06 Add New Room -6

After creating the room, this is how it looks like in room

07 **Change the Room Image -1**

Click on the image

08 **Change the Room Image -2**

You can choose an image from the Library or from the Camera.

**Note:** Images are done locally, so any image change done in room will only remain on that device.

09 Move to a different room -1

Select the downward arrow on the upper right side.

## 10 Move to a different room -2

Select the room you want to view

11 Move to a different room -3

Once you have selected a room, you will be moved to room

Bedroom

12 Delete the sensor from room -1

Click ⚙ icon --> Settings and enter the Advance settings page

Include Device

Exclude Device

Security Include Device

Add Camera

Setting

Notification

Cancel

Gateway
UID: 9YCDGDNP1JZRVH9SMU51

User Information
User
Email
Password

App Information
Language   English
App Ver.   1.0.1

Gateway Information
Gateway Ver.   1.70
Gateway Timezone (GMT+08:00)
Wifi Network

Reboot Gateway
Backup Setting
Restore Setting
Advance Setting

Show gateway siren
Lock setting page

APP Operation Guide
Room Setting

13 Delete the sensor from room -2

Click "**Room**"

Close   **Title**

Sensor   Room   Scene

Macro   Schedule   +

Back   Next

14 Delete the sensor from room -3

Click the Room name



Close   **Title**

Office

+

Back   Next

APP Operation Guide
Room Setting

15 Delete the sensor from room -4

Click "**trash can**" icon and drag the sensor to the bottom trash can

16 Delete the Room

Click the "**trash can**" icon and drag room to the trash can icon.

AirLive IOT
Smart Life For Home

Scene

Scene Setting

Create Multiple Actions

01 Add New Scene -1

Click ⚙ icon --> Settings and enter the Advance settings page

APP Operation Guide
Scene Setting

02 Add New Scene -2

Click "**Scene**"


03 Add New Scene -3

Click "**+**" to add new Scene.

04 Add New Scene -4

Provide a name for the Scene.

05 Add New Scene -5

Click "+" to add sensors to a Scene.

06 Add New Scene -6

After adding the sensor, user can set the sensor action.

07 Add New Scene -7

After creating the scene, this is how it looks like in scene.

Note: Click on the scene and sensors will do what it was set to do.

Air Live

Smart Life IOT For Home

Macro

## Marco Setting

Create If-Then Conditions

---

01 Add New Macro -1

Click ⚇ icon --> Settings and enter the Advance settings page

## 02 Add New Macro -2

Click "**Macro**"

Back   Next

03 Add New Macro -3

Click "**+**" to add new Macro.

Back   Next

# APP Operation Guide
Marco Setting

04 Add New Marco -4

Provide a name for the Macro.

05 Add New Marco -5

Setting up the IF This Then That (ITTT)
Ex: If door is opened, then Plug will
turn ON.

06 Add New Marco -6

To specify the duration, click the duration and set the time.

07 Add New Marco -7

To receive a alert when the macro is triggered, tap the switch beside the notification.

08 Add New Marco -8

After creating the marco, you can now turn the marco on/off on your phone.

Air Live
Smart Life IOT For Home

**Schedule**

Schedule Setting

01 Add New Schedule -1

Click ⚙ icon --> Settings and enter the Advance settings page

02 Add New Schedule -2

Click "**Schedule**"

APP Operation Guide
Schedule Setting

03 Add New Schedule -3

Click "+" to add new Schedule.

04 Add New Schedule -4

Provide a name for the schedule.

05 Add New Schedule -5

Setting up the schedule.
Note: Once a Scene/Macro is used, other sensors cannot be added.

06 Add New Schedule -6

After creating the schedule, you can now turn it on/off on your phone.

Smart Home Kit QIG for APP