

1. Please login to WMU-6500FS setup the permission setting , Select Storage configuration→Access

Control click Authorization mode, Press Save





2. In the Quota configuration Please Enable setting, Press Save



3. After the setup configure, Please click save。 User configuration, will appear following

message, then click save







4. Then please format your hard driver (public folder , private folder)



5. After apply will appear following message. Please click ok.







6. Format hard driver

🗿 AirLive WMU-6500FS - Microsoft Internet Explorer	
檔案 (E) 編輯 (E) 檢視 (Y) 我的最愛 (A) 工具 (I) 說明 (H)	1
🔇 上一頁 · 🚫 · 🖹 🗟 🏠 🔎 搜尋 ☆ 我的最爱 🧐 🔗 - 🌺 🖂	-28
網址① 🙆 http://192.168.10.100:2005/index.htm 🛛 🔽 🄁 移至	連結 >>
Formatting	
1st partition is formating44 %	
Network Settings	
Storage Configuration	
Advanced Tools	
Misc.	
Download Assistant	
Logout	
② 完成	

7. After Format, WMU-6500FS will reboot, After reboot please login WMU6500FS and click Storage

configuration \rightarrow Access control \rightarrow user configuration setup user, password and folder

🖄 AirLive WMU-6500FS - Microsoft Internet Explorer 📃 🗖 🔀					
檔案 (Ε) 編輯 (E) 檢視 (V)	我的最愛(A)	L具(I) 説明(H)			
③ 上一頁 · ◎ · []	🖻 🖻 🏠 🎾	🔵 搜尋 🥎 我的	服要 🚱 😂 •	🎍 🖃 🦓	
網址D 🕘 http://192.168.10.3	100:2005/index.htm		~	▶ 移至 連結 ≫	
	Disk Utility	File Sharing	Access Control	File Browser	
Air Live	User Access C	onfiguration —			
Status	Username	Password	<u>Quota(MByte</u>	<u>s)</u>	
Network Settings					
Storage	User Name	(M	lax. 20 users)		
Configuration	Password				
Advanced Tools	Quota	MBytes	Add Delete C	ancel	
X	Administrator	secup			
Misc.	account	None	Save		
Download Assistant					
Logout			Quota	Status Back	
8 完成			2 網	祭網路	





8. Adding new user

AirLive WMU-6500FS -	Microsoft Interne	t Explorer		
檔案(F) 編輯(E) 檢視(V)) 我的最愛(<u>A</u>) :	工具(I) 說明(H)		A .
③上─頁 • ◎ - [2 🙆 🟠 🌶	🔎 搜尋 大 我的	最愛 🧭 🔗 -	S 🗟 🕹
網址D) 🙆 http://192.168.10.	100:2005/index.htm		~	移至 連結 ※
	Disk Utility	File Sharing	Access Control	File Browser
Air Live'	User Access (onfiguration —		
Status	Username	<u>Password</u>	<u>Quota(MByte</u>	<u>s)</u>
X				
Network Settings				
Storage	User Name c	amera (M	lax, 20 users)	
Configuration	Quota 2	000 MBytes	Add Delete C	ancel
Advanced Tools	Administrator	Setup		
Ă	Administrator	None	V Save	
Misc.	account	NL		
Assistant				
Logout			Quota	Status Back
			(door	
⑧ 完成			(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	祭網路

9. Press add to add new user

🚰 AirLive WMU-6500FS -	Microsoft Interne	t Explorer			
檔案(F) 編輯(E) 檢視(V)	我的最愛(<u>A</u>) 二	L具(I) 說明(H)			
③ 上一頁 • ◎ • Ⅰ	3 🗟 🏠 🔎	🔵 搜尋 🥎 我的	助最愛 🕢 🔗 -	è 🗟 🖏	
網址(D) 🕘 http://192.168.10.1	00:2005/index.htm		~	▶ 移至 連結 ≫	
	Disk Utility	File Sharing	Access Control	File Browser	
Air Live'	User Access C	onfiguration —			
Status	<u>Username</u>	<u>Password</u>	<u>Quota(MByte</u>	<u>s)</u>	
\leq	camera	*****	2000		
Network Settings					
Storage	User Name	(M	lax. 20 users)		
Configuration	Password				
	Quota	MBytes	Add Delete C	ancel	
	Authorization user list changed right now! Administrator Setup				
Misc.	Administrator	None	Save		
Download	account				
Assistant					
Logout					
			Quota	Status Back	
) ⑧ 完成			(2) 網路	祭網路	





^{10.} Please type your WMU6500FS ip address as //192.168.10.100 check if your WMU6500FS have

been complete setup the permission level

💈 samba server (192.168.10.100)	
檔案(E) 編輯(E) 檢視(Y) 我的最愛((A) 工具(I) 說明(H) 🦧 🦧
③ 上─頁 • ② • 参	幸 🍋 資料夾 💷 -
網址(1) 🕄 \\192.168.10.100	移至
 網路工作 ※ <	Eamera Configure Public
■ 院板口建筑和64 07 IF 安直 的圆示 其他位置 《	usb_disk
 ▲ Mshome ◆ 我的電腦 ▲ 我的文件 ▲ 共用文件 ◆ 印表機和傳真 	
詳細資料 🙁	
samba server (192.168.10.100)	

11. Please login to your WMU6500FS (insert username, password for login)





12. Please check the location the permission that have been set for camera recording. (copy the ip

address)



13. login to the WL5460CAM and click Advanced→Tools→Recording

Air	Liv	e	Legent Help		CO2		vered by Ovis
nome basic i	Video	Network +	Mireless >	Tools 🕨	Account	Timezone	iMode
	Habb	Hotholik	111101000	Recording	Port	Mail	Backup
Advanced >> Re	ecording						
	Uplo	ad video to Netw Login Method User Name Password Path	Anonymou ***** V192.168.1	r 15 💌] c	Test	
		Shared Folder №	1ode ile Number 2 Size 1	24 1000(MB)			
		Recording Meth ● Always ○ Schedule Day Time	od Dou Sur Start	n Tue W	ed 🗌 Thu 🗌	Fri Sat	





14. Enable Upload video to network share folder , Login method choose Account and insert the

username and password。 In the path please paste the location that you have been copy just now.

Login Method	Account
User Name	camera
Password	•••••
Path	\\192.168.10.100\camera Test
O Shared File S	Size 1000 (MB)
Recording Metho	d
O Schedule	
Dav	Mon Tue Wed Thu Fri Sa
, 	Sun

15. Press Path Test button (check if your path are working or not.)

10.	🖄 http://192.168.10.10 - ₩ 🔳 🗖 🗙	
L/ ed	Test status:Success	Contract
Jplo	Close	
F		
		Test
	《 湘除湖路	





16. Please choose - Recording method (Always or Schedule), press Apply. Then you can start

recording 。



