

A: You should refer the the section in your manual for more detail instruction on Internet setup.

1. Open your web browser and enter your Gateway's IP address to configure the web management. The default IP is **192.168.0.1**, user's name "eitg", password is "123"
2. Please refer to your user's guide on how to setup the VoIP gateway/router's WAN port for Internet connection.
3. **Dynamic DNS:** If you have dynamic IP address, please make sure to sign up with Dyndns.org and configure your Dynamic DNS setup from "**NAT->Advanced Features->Dynamic DNS**" in the left menu.
 - Please make sure when signing up with dyndns.org. Only choose a domain that ends with "dyndns.org". For example, please choose "myname.dyndns.org". Do not choose "myname.gotdns.org"..etc.
 - If you have a VoIP Gateway Router, please make sure to enter only "myname" in the Hostname field. Do not enter the entire domain name. Refer to the graph below:

The screenshot shows a web interface with two main panels. The left panel, titled "NAT Advanced Features Menu", has an orange background and contains a list of links: DMZ, Virtual Servers, Port Forwarding, Special Applications, Access Control, and Dynamic DNS (highlighted in red). Below this list are links for "Help" and "Back To NAT Menu". The right panel, titled "DDNS Settings", has a yellow background and contains several input fields: "Dyn-DNS" (a dropdown menu set to "on"), "Server Name" (text box with "dyndns"), "Host Name" (text box with "myname"), "User Name" (text box with "myname"), and "Set User Password" (password box with 10 dots). An "OK" button is located at the bottom right of the DDNS Settings panel.

- After Save and Reboot. Please go to the "System Status" in the beginning menu to check whether the Dynamic DNS is up.

		<div> <div> <h3>Main Menu</h3> <ul style="list-style-type: none"> NAT VOIP System Status Firmware Update </div> <div> <h3>IMG System Status</h3> <h4>WAN Interface Parameters</h4> <ul style="list-style-type: none"> IP TOS: 0 0 0 0 MAC address: 00-50-2d-00-57-7f Dynamic DNS: Enabled Status: Up Access Mode: PPPoE State: Connected IP Address: 218.174.141.128 <h4>LAN Interface Parameters</h4> <ul style="list-style-type: none"> MAC Address: 00-50-2d-00-57-7e IP address: 192.168.0.1 Subnet mask: 255.255.255.0 DHCP server: Enabled No. of DHCP clients: 30 Starting client addr: 192.168.0.10 <h4>Firmware Version</h4> <ul style="list-style-type: none"> Integrated Media Gateway Version: Ver 1.06 Boot Load Version: 1.01 DSP Image Version: 8.1.2.1. TSG Version: R8.0 Gateway (Build 4) </div> </div>
--	--	--

4.	<p>DNS INFO: For Gateways without router function (VoIP-422/404/440/800), you need to set the DNS server information. Please use telnet or console port to get into the command line. Below is the example procedure:</p>
	<div> <div>(1)</div> <div>Telnet 192.168.0.1</div> </div>
	<div> <div>(2)</div> <div>Enter the user's name and password</div> </div>
	<div> <div>(3)</div> <div>On the command prompt, type:</div> </div>
	<div> <ul style="list-style-type: none"> set h323 dns_ip <DNS IP address> config activate config store reboot the machine </div>
	<div> <div>(4)</div> <div>*note the <DNS IP address> is the IP address of your ISP's DNS server. If you don't know what it is, you can use 168.95.1.1 instead.</div> </div>
5.	<p>Working with Router: If you have VoIP Gateways (VoIP-422/404/440/800) and you want to connect it under a router. You need to open virtual server ports in order to let the H.323 traffic go through the gateway. Please use one of the methods below (not both):</p>
	<div> <ul style="list-style-type: none"> Open the DMZ port on your router to the gateway. </div>

- | | | |
|--|--|--|
| | | <ul style="list-style-type: none">• Open the following virtual server ports to the gateway: |
| | | <ul style="list-style-type: none">○ TCP port range from 1000 to 5000○ UDP port range from 30000 to 31000 |
| | | <ul style="list-style-type: none">• Please note that the H.323 VoIP use TCP port 1720 for Call Signal. And UDP 30000 for RTP. If your ISP blocks those ports, you can change it by going to "VoIP->H.323->General Settings" on the Web UI. If changed, be sure both side must use the same Call Signal and RTP port. |