


- As AirMax2 is powered on, please install the cable between AirMax2 and PC and check whether the network icon is like the picture.  If so, AirMax2 and PC are connected successfully. And the Link Led is on. If the LAN is not normal, please try to re-power AirMax2.
- After AirMax2 is on, please wait until the boot procedure finish. It is about 1-2 minutes. Please use ping command to check whether the connection is ok. Please refer to the below. If AirMax2 responses, it means the connection is ok. Please help execute the command like below : “arp -d”. Please execute the command many time until it shows the message “ The specified entry was not found.

```
C:\>ping -t 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Reply from 192.168.1.1: bytes=32 time=2ms TTL=64
Reply from 192.168.1.1: bytes=32 time<1ms TTL=254
Reply from 192.168.1.1: bytes=32 time=1ms TTL=254
Reply from 192.168.1.1: bytes=32 time<1ms TTL=254
Reply from 192.168.1.1: bytes=32 time=1ms TTL=254
```

```
C:\>arp -d
The specified entry was not found
```

- If the PC has more than one network card, please avoid setting the same segment IP address as the one that is connected to AirMax2.

After doing the above steps, if it still could not enter web console, please help reset the AirMax2 to factory default setting. Please execute the procedure as AirMax2 finishes boot. Please refer to the reset at the user manual page 18.